

Symantec NetBackup™ Appliance Hardware Installation and Initial Configuration Guide

Release 2.6

NetBackup 52xx

The software described in this book is furnished under a license agreement and may be used only in accordance with the terms of the agreement.

Documentation version: 2.6

PN: 21316366

Legal Notice

Copyright © 2013 Symantec Corporation. All rights reserved.

Symantec, the Symantec Logo, the Checkmark Logo and NetBackup are trademarks or registered trademarks of Symantec Corporation or its affiliates in the U.S. and other countries. Other names may be trademarks of their respective owners.

This Symantec product may contain third party software for which Symantec is required to provide attribution to the third party ("Third Party Programs"). Some of the Third Party Programs are available under open source or free software licenses. The License Agreement accompanying the Software does not alter any rights or obligations you may have under those open source or free software licenses. Please see the Third Party Legal Notice Appendix to this Documentation or TPIP ReadMe File accompanying this Symantec product for more information on the Third Party Programs.

The product described in this document is distributed under licenses restricting its use, copying, distribution, and decompilation/reverse engineering. No part of this document may be reproduced in any form by any means without prior written authorization of Symantec Corporation and its licensors, if any.

THE DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID. SYMANTEC CORPORATION SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, PERFORMANCE, OR USE OF THIS DOCUMENTATION. THE INFORMATION CONTAINED IN THIS DOCUMENTATION IS SUBJECT TO CHANGE WITHOUT NOTICE.

The Licensed Software and Documentation are deemed to be commercial computer software as defined in FAR 12.212 and subject to restricted rights as defined in FAR Section 52.227-19 "Commercial Computer Software - Restricted Rights" and DFARS 227.7202, "Rights in Commercial Computer Software or Commercial Computer Software Documentation", as applicable, and any successor regulations. Any use, modification, reproduction release, performance, display or disclosure of the Licensed Software and Documentation by the U.S. Government shall be solely in accordance with the terms of this Agreement.

Symantec Corporation
350 Ellis Street
Mountain View, CA 94043

<http://www.symantec.com>

Printed in the United States of America.

10 9 8 7 6 5 4 3 2 1

Technical Support

Symantec Technical Support maintains support centers globally. Technical Support's primary role is to respond to specific queries about product features and functionality. The Technical Support group also creates content for our online Knowledge Base. The Technical Support group works collaboratively with the other functional areas within Symantec to answer your questions in a timely fashion. For example, the Technical Support group works with Product Engineering and Symantec Security Response to provide alerting services and virus definition updates.

Symantec's support offerings include the following:

- A range of support options that give you the flexibility to select the right amount of service for any size organization
- Telephone and/or Web-based support that provides rapid response and up-to-the-minute information
- Upgrade assurance that delivers software upgrades
- Global support purchased on a regional business hours or 24 hours a day, 7 days a week basis
- Premium service offerings that include Account Management Services

For information about Symantec's support offerings, you can visit our website at the following URL:

www.symantec.com/business/support/

All support services will be delivered in accordance with your support agreement and the then-current enterprise technical support policy.

Contacting Technical Support

Customers with a current support agreement may access Technical Support information at the following URL:

www.symantec.com/business/support/

Before contacting Technical Support, make sure you have satisfied the system requirements that are listed in your product documentation. Also, you should be at the computer on which the problem occurred, in case it is necessary to replicate the problem.

When you contact Technical Support, please have the following information available:

- Product release level
- Hardware information

- Available memory, disk space, and NIC information
- Operating system
- Version and patch level
- Network topology
- Router, gateway, and IP address information
- Problem description:
 - Error messages and log files
 - Troubleshooting that was performed before contacting Symantec
 - Recent software configuration changes and network changes

Licensing and registration

If your Symantec product requires registration or a license key, access our technical support Web page at the following URL:

www.symantec.com/business/support/

Customer service

Customer service information is available at the following URL:

www.symantec.com/business/support/

Customer Service is available to assist with non-technical questions, such as the following types of issues:

- Questions regarding product licensing or serialization
- Product registration updates, such as address or name changes
- General product information (features, language availability, local dealers)
- Latest information about product updates and upgrades
- Information about upgrade assurance and support contracts
- Information about the Symantec Buying Programs
- Advice about Symantec's technical support options
- Nontechnical presales questions
- Issues that are related to CD-ROMs, DVDs, or manuals

Support agreement resources

If you want to contact Symantec regarding an existing support agreement, please contact the support agreement administration team for your region as follows:

Asia-Pacific and Japan	customercare_apac@symantec.com
------------------------	--

Europe, Middle-East, and Africa	semea@symantec.com
---------------------------------	--

North America and Latin America	supportsolutions@symantec.com
---------------------------------	--

Contents

Technical Support	4
Chapter 1 NetBackup 5230 installation	10
Product documentation	10
Product overview	11
Dimensions	11
Appliance front panel	12
Appliance rear panel	14
About the FC HBA target and initiator ports	15
Storage shelf front panel	16
Storage shelf rear panel	17
Hardware startup sequence	18
About hardware installation	19
Tools	20
Checking the shipping packages	20
ESD-preventive measures	22
Environmental specifications	22
Ensuring rack readiness	23
Installing the hardware	24
Removing the protective film from the storage shelf	24
Installing the Symantec Storage Shelf guide rails	25
Installing the Symantec Storage Shelf into a rack	26
Installing the NetBackup appliance guide rails	27
Installing the NetBackup appliance into a rack	28
About the cables	29
Connecting the VGA cable	29
Connecting the small form-factor pluggable (SFP+) transceivers	30
Connecting the network cables	31
Connecting the appliance to a storage shelf	32
Connecting the power cables	33
Checking information before turning on the devices	34
Turning on the storage shelf	35
Turning on the Appliance	35

Chapter 2	NetBackup 5220 installation	37
	Product documentation	37
	Product overview	38
	Dimensions	39
	NetBackup 5220 front and rear panels	40
	NetBackup 5220 Appliance front and rear panels - details	40
	Appliance control panel	43
	Symantec Storage Shelf front and rear panels	45
	Symantec Storage Shelf front and rear panels - details	46
	Hardware startup sequence	48
	About hardware installation	49
	Hardware installation flow	49
	Environmental requirements	51
	Environmental checklist	51
	Power supply overview	53
	Electrical safety	53
	Heat dissipation guidelines	54
	Air flow	54
	Tools and meters	55
	ESD-preventive measures	57
	Ensuring rack readiness	59
	Installing hardware into racks	60
	Removing the protective film from the storage shelf	60
	Installing the Symantec Storage Shelf guide rails	61
	Installing the Symantec Storage Shelf into a rack	61
	Installing the NetBackup 5220 guide rails	62
	Installing the NetBackup 5220 Appliance into a rack	62
	About the cables	63
	Cable examples	63
	Connecting the VGA cable (optional)	65
	Connecting the network cables	65
	Connecting the optical fibres	66
	Connecting the NetBackup 5220 power cables	67
	Connecting the Symantec Storage Shelf power cables	67
	Connecting an appliance and one or two storage shelves	68
	Turning on the hardware	70
	Check before turning on	70
	Turning on the storage shelf and the appliance	71
	Turning off the appliance and the storage shelves	73

Chapter 3	Initial configuration	75
	About appliance configuration guidelines	75
	About appliance system configuration sequence	78
	About NetBackup 52xx appliance roles	79
	About IPv4-IPv6-based network support	79
	About the initial configuration pages in the NetBackup Appliance Web Console	81
	About the Symantec NetBackup 52xx Appliance initial configuration checklist	91
	Performing the initial configuration on a NetBackup 52xx appliance from the NetBackup Appliance Web Console	92
	Performing the initial configuration on a 52xx master server appliance from the NetBackup Appliance Shell Menu	108
	Configuring a master server to communicate with an appliance media server	114
	Performing the initial configuration on a 52xx media server appliance from the NetBackup Appliance Shell Menu	116
	About configuring the maximum transmission unit size	125
	Installing NetBackup client software from the packages	126
	Installing NetBackup client software on clients through CIFS and NFS shares	128
Appendix A	Initial configuration checklist	130
	Symantec NetBackup 52xx Appliance initial configuration checklist	130
Appendix B	Adding a second storage shelf to an operational appliance	135
	About adding a second Symantec Storage Shelf to an operational NetBackup 52xx appliance	135
	Installing and connecting a second Symantec Storage Shelf to an operational NetBackup 52xx appliance	136
	Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Web Console	138
	Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Shell Menu	139
Index		141

NetBackup 5230 installation

This chapter includes the following topics:

- [Product documentation](#)
- [Product overview](#)
- [About hardware installation](#)
- [Installing the hardware](#)
- [About the cables](#)
- [Checking information before turning on the devices](#)

Product documentation

This document is available to customers and end users. This chapter describes hardware installation for the NetBackup 5230 appliance and storage shelves.

[Table 1-1](#) and [Table 1-2](#) list documents for the NetBackup 5230 Appliance and the Symantec Storage Shelf.

Table 1-1 NetBackup Appliance and Symantec Storage Shelf hardware-related documentation

Document	Description
<i>Symantec NetBackup 5230 Appliance and Symantec Storage Shelf Product Description</i>	Describes all aspects of the appliance and the attached storage shelf. Provides general safety, compliance, and environmental information.

Table 1-1 NetBackup Appliance and Symantec Storage Shelf hardware-related documentation (*continued*)

Document	Description
<i>NetBackup 5230 Appliance and Symantec Storage Shelf Safety and Maintenance Guide</i>	Provides detailed safety information. Provides the guidelines for routine monitoring and physical maintenance of the appliance.

Table 1-2 NetBackup Appliance and Symantec Storage Shelf software-related documentation

Document	Description
<i>Symantec NetBackup Appliance Administrator's Guide</i>	Describes the aspects of the NetBackup appliance software, and how to implement a storage pool across your company's network.
<i>Symantec NetBackup Appliance Release Notes</i>	Lists the important information for this specific software release.
<i>Symantec NetBackup Appliance Command Reference Guide</i>	Contains the detailed information about the NetBackup appliance shell commands.

Refer to <http://www.symantec.com/docs/DOC2792> to obtain NetBackup Appliance documentation.

See “[Product overview](#)” on page 11.

Product overview

Two disk drives in the appliance provide the operating system for the appliance and a RAID 1 array. The appliance also includes the eight 1-TB storage disk drives which provide approximately 4TB of storage capacity. Refer to the *Symantec NetBackup 5230 Appliance and Symantec Storage Shelf Product Description* for descriptions of the storage capacities that are available.

Configurations that include at least one Storage Shelf require a SAS RAID controller card that is installed in a PCIe add-in slot in the appliance. The appliance also has the Fibre Channel port cards that are installed in the PCIe slots for all configurations.

See “[Dimensions](#)” on page 11.

Dimensions

The heaviest devices in any equipment rack should be installed in the bottom of the rack. If heavy devices are installed at the top of the rack, the rack may tip over.

Injury to personnel and damage to equipment is very possible. The Symantec Storage Shelf is heavier than the appliance. Therefore, you must install the storage shelf in the bottom of the rack. Install the appliance above the storage shelves.

The appliance weight and dimensions are listed below

- 52 lbs (23.58 kg)
- 27.39" (69.59 cm) deep
- 17.24" (43.8 cm) wide
- 3.45" (8.76 cm) high

The rack rails that are provided for the appliance are extensible to 30" (752mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 30" (752mm) the rails and the appliance cannot be properly installed. The width of the appliance is 19" (482.6mm).

The storage shelf weight and dimensions are listed below:

- 71 lbs (32.2 kg)
- 22.1" (56.1 cm) deep
- 17.6" (44.7 cm) wide
- 3.5" (8.8 cm) high

The rack rails that are provided for the Symantec Storage Shelf are extensible to 36" (914mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 36" (914mm) the rails and the appliance cannot be properly installed. The width of the storage shelf is 19" (482.6mm).

See "[Appliance front panel](#)" on page 12.


Appliance front panel

The front panel of the appliance contains 12 hard disk drive slots and an LED panel.


Every NetBackup 5230 appliance contains 12 disk slots. They are numbered from 0 to 11, starting at the lower left-hand corner. The appliance has two SAS disks that are installed in slots 0 and 1, which are used for the operating system and mirrored RAID1 support. Two active system disks allow one of the disks to be swapped while the appliance is running.

Eight storage disks are installed in slots four through 11. The hot spare is in slot 11, in the top right-hand corner of the appliance.

The system disk drives are circled in red. The storage disk drives are circled in yellow.



The NetBackup 5230 does not require a Symantec Storage Shelf to provide storage. The standard appliance contains the 1-TB storage disks which provide 4-TB of formatted storage capacity. If more than 4-TB of storage is needed Symantec Storage Shelves can be added.



A small panel is attached to the right side of the appliance. The panel contains system LEDs and operations buttons. The LEDs provide information about the functionality of the appliance. The details are provided in [Table 1-3](#).

Table 1-3 NetBackup Appliance front panel controls and features

Number	Description
1	AC power button with integrated LED (executes a shutdown before turning off power)
2	Hard drive activity LED
3	System ID button with integrated LED
4	System cold reset button (turns off power instantly)
5	NIC4/eth3 activity LED (on when linked; flashes when in use at the rate of speed)
6	NIC3/eth2 activity LED (on when linked; flashes when in use at the rate of speed)
7	NMI button (This button triggers a nonmaskable interrupt. All server data is lost.)
8	NIC1/eth0 activity LED (on when linked; flashes when in use at the rate of speed)
9	NIC2/eth1 activity LED (on when linked; flashes when in use at the rate of speed)
10	System status LED (green when status is good; amber when faults have occurred)

Each hard disk drive has two LEDs which give the drive status, as shown in the following diagram. The top LED (1) is solid green when the power is on and flashes when the disk drive is active. This LED is known as the **drive activity** LED. The bottom LED (2) displays a solid amber color if a disk drive fault has occurred; otherwise, it is not lit. This LED is known as the **drive fault** LED.



On the left side of the front panel, a black tag can be pulled out to display the serial number of the appliance.



See “[Appliance rear panel](#)” on page 14.

Appliance rear panel

The NetBackup Appliance rear panel provides access to the communication ports, PCIe add-in cards, and the hot-swappable power supplies. The add-in cards are installed at the factory before the appliance ships.





Table 1-4 NetBackup Appliance rear panel

Number	Function
1, 2	Power Supply Modules #1, #2
3	NIC1/eth0, reserved for private networks. The port is a 1Gb connector.
4, 5, 6	NIC2/eth1, NIC3/eth2, and NIC4/eth3 are used for public networks. All three ports are 1Gb connectors.
7	DB-15 VGA connector
8	RJ45 Serial-A port (reserved)
9	USB connectors
10	Remote management (IPMI) port
11	NIC5/eth4 and NIC6/eth5, left to right: 10Gb network connectors for public networks
12	PCIe add-in adapter slots (for SAS RAID Controller, Fibre Channel, and 10Gb Ethernet cards)
13	Serial-B port (reserved)

See [“Storage shelf front panel”](#) on page 16.

About the FC HBA target and initiator ports

Configurations D and E support FTMS. In these configurations Port 1 on each FC HBA card (1) in slots 5 and 6 are configured in Target mode. Port 2 in slots 5 and 6 and all of the other FC ports are configured in Initiator mode.

Figure 1-1 FC HBA card target and initiator ports


Storage shelf front panel

The Symantec Storage Shelf front panel includes 16 drives slots. Each drive slot contains a drive bay, a drive release button, and two LEDs. The bay houses the disk drive module which includes the disk drive and a carrier. The release button lets you remove the drive from the storage shelf. The LEDs provide status and activity information about the drive.

In addition to the drive slots, the front panel includes two sets of three LEDs embedded in the frame. These LEDs provide information about the overall storage system and about the system components.




Table 1-5 Symantec Storage Shelf disk drive LED status indicators (1)

LED name	State	Description
Disk status	Green	Normal operation
	Amber	Abnormal or no operation
Power/activity	Green	Normal operation
	Amber	Abnormal or no operation

Table 1-6 Symantec Storage Shelf system LED status indicators (2)

LED name	State	Description
Power	Not lit	Off
	Solid green	On
Global enclosure status	Not lit	Off
	Solid green	On
	Amber	One power supply offline
	Red	Both power supplies offline
Reserved	N/A	N/A


Table 1-6 Symantec Storage Shelf system LED status indicators (2) (*continued*)

LED name	State	Description
I/O Module 1 activity	Not lit	No activity
	Flashes green	Activity
I/O Module 2 activity	Not lit	No activity
	Flashes green	Activity
Heartbeat	Not lit	System off
	Flashes green	Normal operation

See [“Storage shelf rear panel”](#) on page 17.

Storage shelf rear panel

The rear panel of the Symantec Storage Shelf contains two I/O modules and two power supplies. The I/O modules make the storage capacity in the storage shelf available to the RAID controller in the NetBackup Appliance. This section provides information about the rear panel of the storage shelf.


Table 1-7 Storage Shelf rear panel

Number	Element	Details
1	SAS_IN port LED	Not lit - no link available Solid green - link available Flashes green - activity Red - power supply failure

Table 1-7 Storage Shelf rear panel (*continued*)

Number	Element	Details
2	SAS_IN port	Connected to the NetBackup Appliance
3	SAS_OUT port	Connected to a second storage shelf, if used
4	SAS_OUT port LED	Not lit - no link available Solid green - link available Flashes green - activity Red - power supply failure
5	I/O module LED	Not lit - off Solid green - ready Flashes green - N/A Red - starting up
6	Power supply LED	Not lit - power is not detected Solid green - power is ok Flashes green - power supply is not turned on Red - power cannot be turned on

Note: When the Symantec Storage Shelf starts, the primary I/O module (on the left side of the rear panel) starts first. Its LED turns green a few seconds after the start. The LED of the secondary I/O module (on the right of the rear panel) starts after the primary module is operational.

See [“Hardware startup sequence”](#) on page 18.

Hardware startup sequence

Appliances such as the NetBackup 5220 Appliance required a matched set of appliance and storage shelf and a specific sequence to start the devices. These specifications are not required for the NetBackup 5230 Appliance.

The startup order for the NetBackup 5230 Appliance and storage shelves follows.

- You do not need to match the appliance to a storage shelf. The boot order is preset and static.
- Importing of the storage configuration is now automatic. You do not need to manually import a foreign configuration.

- You must turn on any and all storage shelves first, then turn on the appliance. This sequence ensures that the appliance recognizes the storage shelves.
- Next, you can proceed to the initial configuration of your appliance and storage units.

See [“Turning on the storage shelf”](#) on page 35.

See [“Turning on the Appliance ”](#) on page 35.

About hardware installation

Warning: NetBackup equipment and containers can weigh in excess of 70 lbs (31.75 kg). Improper handling can result in injury or equipment damage. Use appropriate techniques, tools, and materials when handling NetBackup equipment.

The hardware installation flow is as follows:

- Understand the NetBackup Appliance and the Symantec Storage Shelf.
- Check safety precautions.
- Check installation requirements.

The rack rails that are provided for the NetBackup 5230 Appliance are extensible to 30" (752mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 30" (752mm) the rails and the appliance cannot be properly installed. The width of the appliance is 19" (482.6mm).

The rack rails that are provided for the Symantec Storage Shelf are extensible to 36" (914mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 36" (914mm) the rails and the appliance cannot be properly installed. The width of the storage shelf is 19" (482.6mm).
- Unpack the devices.
- Install rack rails in the equipment racks for the NetBackup Appliance and Symantec Storage Shelf. The storage shelf is heavier than the appliance. All storage shelves should be installed at the bottom of the rack, below the appliance.
- Install the NetBackup Appliance and Symantec Storage Shelf into the rack rails. The appliance height is 2U and the storage shelf height is 3U. Guide pins on the devices are used to position the devices correctly on the rail. It sits completely inside the rack.

- Screws are provided with the hardware as needed. Insert the screws into the rack. Use the screws in back and in front to secure the devices to the rack.
- If your appliance rails have built-in pins instead of screws, secure the pins in the rack holes. The blue pin indicates the bottom of the rail.
- Connect the two SAS cables between the NetBackup Appliance and the Symantec Storage Shelf.
- Plug the two power cables which are required for each device into appropriate AC power supplies.
- Turn on the storage shelf first, and let it initialize. If you have two storage shelves, turn on the storage shelf that is not connected to the appliance. When that storage shelf has initialized turn on the other storage shelf and let it initialize.
- Turn on the NetBackup appliance.
- Ensure that the devices operate properly, and initialize the configuration for the device.

Tools

The following tools and supplies are required for hardware installation.

- Phillips screwdrivers M3-M6
- Diagonal cutting pliers
- Knife (for opening cartons)
- ESD protective clothes, wrist strap, or gloves
- Multimeter (optional)

Checking the shipping packages

Before unpacking devices, check that the packages are intact and undamaged.

The appliance package should include the following items:

- The NetBackup Appliance
- Mounting rails for the appliance
- Snap-in screw locks for attaching the appliance to the rack
- Two AC-power cords for the appliance
- A portfolio containing license information, documentation, and a USB stick.

If one or more storage shelves are included with the appliance, each storage shelf package should contain the following:

- The Symantec Storage Shelf
- Mounting rails for each shelf
- Screws to attach the rails to the rack
- Snap-in screw locks to secure the screws that attach the rails to the rack
- Two AC-power cords for each shelf
- Two SAS cords for each shelf

Before you unpack the devices, perform the following checks.

To check devices prior to unpacking

- 1 Verify that the quantity of the packages which were received matches the shipping documentation quantity.
- 2 Check that the packages are intact. If the packages are severely damaged or are wet, perform Step 5.
- 3 Check the Shock Watch label which is attached to the shipping container. If the indicator is red, perform Step 5.



- 4 If the packages are intact, unpack the devices.
- 5 If the packages are not intact, stop unpacking and identify any problems. Report the situation to the local engineering manager.

Caution: Store any unpacked systems indoors to protect them from the weather. If products are damaged, take photographs of the damaged goods and archive them in a safe place along with any shipping records and invoices.

See “[ESD-preventive measures](#)” on page 22.

ESD-preventive measures

ESD-preventive clothes, wrist straps, and gloves prevent static electricity from damaging the devices. ESD-preventive clothes provide the best protection, followed by a protective grounded wrist strap, and lastly by protective gloves.

Symantec recommends that you wear ESD-preventive clothes if they are available. If they are not available, wear a protective grounded wrist strap, or if a wrist strap is unavailable, protective gloves.

If you wear ESD-preventive clothes, be sure to fasten the buttons.

Wearing an ESD-preventative wrist strap or band

- 1 Stretch your hand through the ESD-preventive wrist strap or band.
- 2 Fasten the ESD-preventive wrist device to fully touch your skin.
- 3 An ESD-preventive wrist strap has a plug or metal clip. Perform one of the following steps depending on your environment.
 - Insert the plug into the ESD jack on a workbench.
 - Attach the metal clip to an unpainted metal surface on the appliance, rack cabinet, or the specific component you are working on.

You can verify that you are ESD-free with an appropriate meter. Use the instructions that apply to your meter.

See [“Environmental specifications”](#) on page 22.

Environmental specifications

[Table 1-8](#) lists the requirements for the NetBackup appliance and storage devices.

Table 1-8 Environmental requirements

Component	Requirement
Storage shelf nominal voltage	220VAC
Operating temperature	10°C to 35°C (50°F to 95°F)
Storage temperature	-10°C to 50°C (14°F to 122°F)
Transportation temperature	-40°C to 60°C (-40°F to 140°F)
Relative humidity operating range	10% to 80%
Relative humidity storage range	10% to 90%
Relative humidity transportation range	5% to 90%

Table 1-8 Environmental requirements (*continued*)

Component	Requirement
Relative humidity operating gradient	10°C (50°F) per hour maximum
Relative humidity storage gradient	15°C (59°F) per hour maximum
Operating altitude	<p>-30 meters to 3,000 meters (-98.4 ft to 9842.5 ft)</p> <p>In altitudes from -60 meters to +1,800 meters, the ambient temperature ranges from 5°C to 35°C.</p> <p>When the altitude ranges from 1,800 meters to 3,000 meters, the environment temperature decreases by 0.6°C if the altitude increases by 100 meters.</p>
Storage altitude	-30 meters to 3,000 meters
Noise	<p>< 72 dB(A)</p> <p>This value reflects the maximum noise of the NetBackup appliance when the ambient temperature is 25°C (77°F).</p>

See [“Checking the shipping packages”](#) on page 20.

Ensuring rack readiness

The rack should be checked as follows:

- Ensure that the rack is properly installed and grounded.
- The rack rails that are provided for the NetBackup 5230 Appliance are extensible to 30" (752mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 30" (752mm) the rails and the appliance cannot be properly installed. The width of the appliance is 19" (482.6mm).
- The rack rails that are provided for the Symantec Storage Shelf are extensible to 36" (914mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 36" (914mm) the rails and the appliance cannot be properly installed. The width of the storage shelf is 19" (482.6mm).
- Ensure that the rack is at least 100 cm (approximately 3 feet) away from the walls.

- Ensure that the clearance between any racks is at least 120 cm (approximately 4 feet) for maintenance, adequate ventilation, and effective heat dissipation.
- Ensure that other equipment does not prevent air transfer between the cabinet and the room. Adequate distance is necessary for cooling of the devices.

Installing the hardware

This section describes the steps required to install guide rails into the rack for the appliance and for the storage shelf. When the guide rails are secured you can install the hardware. Be sure to install the storage shelf below the appliance in the rack. The storage shelf is heavier than the appliance and should be located as low as possible in the rack. If you have two storage shelves, install both shelves below the appliance.

See [“Removing the protective film from the storage shelf”](#) on page 24.

Removing the protective film from the storage shelf

The Symantec Storage Shelf ships with a clear, protective film on the top, bottom, and sides of the chassis. The front panel and the rear panel do not include any film. You need to remove the film before you install the storage shelf into the rack. The storage shelf does not install properly if the film is not removed.

Two yellow labels sit on top of the rear of the chassis and flop over onto the rear panel. These labels contain the serial numbers of the appliance and the storage shelf.

To remove the protective film and retain the labels

Warning: Make sure that another person is available to help lift the storage shelf.

- 1 Peel the top of the yellow labels from the protective film.
- 2 Do not discard the labels.
- 3 Peel the protective film from the top rear of the storage shelf.
- 4 Replace the labels on the top of the storage shelf or save them in a secure location. You may need to refer to the labels at a later time.
- 5 Lift up one end of the storage shelf and peel the film from the bottom of the chassis.
- 6 When approximately half of the film is removed, lift the other end of the storage shelf and remove the remaining film.

7 Peel the film from the sides of the storage shelf.

8 Discard all of the film.

See [“Installing the Symantec Storage Shelf guide rails”](#) on page 25.

Installing the Symantec Storage Shelf guide rails

The Symantec Storage Shelf is shipped with left and right mounting rails. These rails install in a standard 19-inch rack. The front plates of the rails are marked left and right. Two-inch lips on the bottoms of the rails provide a shelf on which the storage system sits. Extenders built into the rails let you adjust the rails for the depth of the rack.

Caution: Due to the weight of the units, Symantec recommends that storage shelves be installed at or near the bottom of the rack.

Requirements

- 19-inch equipment rack
- Available 3U slot
- Six M5 screws (provided)
- Six cage nuts (provided)
- Number 2 Phillips screwdriver
- Flashlight

To install the Symantec Storage Shelf guide rails

- 1 Locate the left mounting rail in the box in which the Symantec Storage Shelf is shipped. The mounting plate at the front end of the rail is marked Front Left.
- 2 Install snap-in cage nuts in the rack as follows:
 - Locate the M5 snap-in cage nuts in the package in which the storage shelf was sent.
 - Identify the bottom third of the 3U section in the front and back of the rack where you want to install the storage shelf.

Note: The mounting rails are 1U high. The holes used to secure the rail in the rack are in the middle of that height.

- From the inside of the rack, insert snap-in cage nuts in cutouts in the front and back where you want to install the mounting rail. Make sure that the nuts are installed at the same level.
- 3 Orient the left mounting rail so that the lip is at the bottom and on the inside of the rack. You can adjust the length of the rail to fit the depth of the rack.
-
- Note:** The lip on the rail that supports the storage shelf must be on the inside of the rack and at the bottom of the rail.
-
- 4 Align the screw holes in the rail with the snap-in cage nut that you installed in the rack.
 - 5 Insert 5M screws and tighten. Screws are shipped with the unit.
 - 6 Repeat Steps 1 through 5 for the right mounting rail. Be sure that rails are installed at the same height.

Installing the Symantec Storage Shelf into a rack

Caution: Due to the weight of the units, Symantec recommends that storage shelves be install at or near the bottom of the rack.

Warning: A Symantec Storage Shelf weighs about 71.7 lbs (32.5 kg) with disks installed. Use appropriate practices, techniques, and tools when handling these components.

To install the Symantec Storage Shelf into a rack

- 1 Verify that the guide rails are properly installed and securely fastened in the rack.
- 2 Insert snap-in cage nuts in cutouts on both sides of the front of the rack to secure the storage shelf. The snap-in cage nuts must align with the through holes in top third of each ear on the storage shelf when the storage shelf is installed in the rack.



- 3 Slide the storage shelf along the mounting rails into the rack cabinet.
 - 4 Insert M5 screws in the through holes in the ears of the front panel and tighten. The through holes must align with the snap-in cage nuts installed earlier.
- See [“Installing the NetBackup appliance guide rails”](#) on page 27.

Installing the NetBackup appliance guide rails

Before you install the devices in a rack:

- Refer to the *Rail Installation Guide* which is included with the appliance. Several screws that must be used for the rails are included with the guide. If your appliance ships with rails that have pins instead of screws, make sure to secure the pins in the post holes.
- Determine the installation positions of the guide rails in the rack.

To install the rack rails

- 1 Start with the rail on the left side of the rack.
- 2 Keep the inside of the rail facing into the inside of the rack.
- 3 Attach the rail with the screws that are provided.
- 4 Repeat steps one to three for the rail on the right side of the rack.
- 5 Verify that both rails are parallel and fastened securely.




Table 1-9 Appliance guide rail components

Number	Feature
1	Front bracket
2	Outer member
3	Rear bracket
4	Inner member
5	Safety lock pin
6	Release button

See [“Installing the NetBackup appliance into a rack”](#) on page 28.

Installing the NetBackup appliance into a rack

The appliance should be installed above any storage shelves. This configuration allows proper weighting of the rack.

To install the NetBackup appliance into a rack

- 1 Verify that the guide rails are properly installed and securely fastened.
- 2 Insert two snap-in screw locks into the rack immediately underneath the guide rails.

These locks secure the appliance when it is fully installed into the rack.

- 3 Pull out both the rail extenders as far as they can easily and safely extend. The release button should click when the rails have been fully extended.

Warning: The appliance weighs at least 52 lbs (23.58 kg). Use at least two people to lift or move the appliance.

- 4 Lift the appliance with the rear panel facing towards the rear of the rack.
- 5 Tilt the device down towards the back of the rack.
- 6 Insert the two rear "standoff" pegs extending from the side of the device into the rail slots at the back of the rail extenders.
- 7 Slowly drop the front of the device into the rail slots at the front of the rail extenders. A peg in the middle and a peg at the front of the device fit into the rail slots.

- 8 Lift up on the guide rail release buttons and push the device into the rack.
- 9 Fasten the appliance to the rack with the two screws that are attached to the device. Screw them into the snap-in cage nuts previously attached to the rack in the correct position.

See [“About the cables”](#) on page 29.

About the cables

The NetBackup appliances and storage devices use the following types of cables. Some cables are provided with the product, while some cables are optional depending on customer requirements.

Cables shipped with the product:

- AC power cables for connecting the devices to main AC power source
- SAS cables

Cables which the customer must provide:

- 1 Gb/s network cables
- 10 Gb/s network cables
- Fibre Channel cables for client and device connections
- PS/2 to USB adapter cable
- KVM cable

Connecting the VGA cable

When the appliance is initialized, a monitor can be connected to the Video Graphics Array (VGA), and a keyboard can be attached to the USB port. Alternatively, you can connect the VGA to a Keyboard Video Mouse (KVM) adapter or switch.

To connect the VGA Cable

- 1 Insert the connector of a VGA (DB15) cable into the video port on the rear panel of the NetBackup appliance.


See [“Appliance rear panel”](#) on page 14.

- 2 Connect the other end of the cable directly to a monitor, or to a KVM adapter, or KVM switch.

Connecting the small form-factor pluggable (SFP+) transceivers

The NetBackup appliance supports Fibre Channel (FC) tape out PCIe add-in cards and a 10 Gb Ethernet NIC with two ports. The cards connect to other devices through fiber optic cables. Using the tape out card (Fibre Channel) as an example, this section describes how to connect a fiber optic cable. The procedure to connect fiber optic cables is the same for both cards.

The fiber optic cables require Small Form-factor Pluggable (SFP+) transceivers, which are provided with each device having Fibre Channel ports. The diagram shows the SFP (1) and the fiber optic cable which is attached to it (2).



Supported SFPs are listed as follows:

- Finisar
- JDSU

Warning: The laser beams of an optical interface board or inside an optical fibre can cause eye damage. Do not look directly into the transceiver or point the transceiver at another person's eyes.

When connecting optical fibers, note the following:

- An optical transceiver is electrostatic sensitive and it should be placed in an ESD-preventive and dust-proof environment for transportation, storage, and use.
- Optical fibers and optical transceivers not in use must be protected with dust caps seated properly on the connectors. If the optical transceiver is contaminated, carefully clean the optical interface.
- Keep the surface of all optical connectors clean and free from scratches.
- Do not squeeze, distort, fold, or repair an optical fiber.
- Do not bend the optical fiber into a circle with a radius less than 5 cm. Otherwise, the optical fiber may be damaged, which reduces the system performance or causes data loss.


To connect optical fibers

- 1 Put on proper ESD-preventive gloves or wrist straps.
- 2 Take the cap of the optical transceiver out of the interface of the tape out card (two-port 8 Gb FC HBA).
- 3 Remove an optical fiber from its packaging.
- 4 Remove the caps of the optical connectors.
- 5 Plug an optical connector into the interface of the card.
- 6 Ensure that the optical connector is securely inserted into the optical transceiver.
- 7 Connect the other optical connector of the optical fiber to a Fibre Channel switch.

See [“About the cables”](#) on page 29.

Connecting the network cables

The networking ports are accessed on the rear panel of the device. The remote management port is for use by Symantec Technical Support staff or by approved field service technicians. The following picture shows the layout of the network ports. It includes the four 1 Gb Ethernet ports on the left, the two 10 Gb Ethernet ports on the right, and the remote management (IPMI) port.



Caution: The first Ethernet port is configured as NIC1/eth0. This port is used to connect to the customer's private network. This port cannot be used with a public network. The appliance does not operate if the NIC1/eth0 port is connected to a public network.

Ethernet ports NIC2/eth1, NIC3/eth2, NIC4/eth3, NIC5/eth4, and NIC6/eth5 can be connected to public networks.

See [“Connecting the small form-factor pluggable \(SFP+\) transceivers”](#) on page 30.

Connecting the appliance to a storage shelf

The SAS RAID controller PCIe card is inserted in one of the add-in adapter slots. This card is installed at the factory. If needed, an authorized field technician can add a new card or replace an existing card. Customers are not permitted to perform these operations.

Serial Attached SCSI (SAS) cables must be used to connect the appliance with one or more storage shelves.

When two shelves are used, the SAS_OUT port in the first storage shelf is connected to the SAS_IN port in the second storage shelf. The following diagram shows the NetBackup 5230 attached to two storage shelves.




Table 1-10 Appliance and storage shelf components

Numbers	Feature
1	SAS RAID controller
2	1 Gb Ethernet ports
3	Serial port
4	Remote management (IPMI) port
5	10 Gb Ethernet ports
6	Storage shelves

To connect the SAS cables

- 1 Connect a SAS cable to each of the two ports marked "SAS IN" on the storage shelf.
- 2 Connect each SAS cable to a SAS port on the add-in RAID controller adapter on the appliance.
- 3 When using a second storage shelf with the NetBackup 5230, connect the SAS OUT ports on the first storage shelf to the SAS IN ports on the second storage shelf.

See ["Connecting the power cables"](#) on page 33.

Connecting the power cables

Caution: The equipment should be completely installed and all network cables should be connected before any devices are connected to power sources.

The NetBackup appliance has two power modules that are accessible on the rear panel of the device. Each module requires a separate AC power cable. Plug one end of a power cable to a power module, and then plug the other end into a 120 VAC socket.

The storage shelf also has two power modules that are accessible on the rear panel of the device. Each module requires a separate AC power cable. Plug each module into a 120 VAC socket.

Checking information before turning on the devices

Check the information in [Table 1-11](#) after the hardware installation and cable connections are complete, but before the devices are turned on.

Note: Do not attach external devices, such as tape drives or SAN clients, to the appliance until this process has been completed.

Warning: Confirm that all power to the devices is turned off to prevent personnel injuries and to prevent damage to the devices.

Verify that the devices and cables are installed correctly. The following table provides instructions for checking the device installation.

Table 1-11 Installation confirmation

Component	Correct installation	Incorrect installation
Symantec Storage Shelf	The storage shelf is placed securely in the lowest portion of the rack cabinet.	The storage shelf is insecurely mounted or mounted too high within the rack cabinet.
NetBackup appliance	The NetBackup appliance is placed securely in the lower portion of rack cabinet, above the storage shelf.	The NetBackup appliance is insecurely mounted or mounted too high within the rack cabinet.
AC power cables	The AC power cables of the NetBackup appliance and storage shelf are connected to the power modules and the AC power supply.	Only one power cable is connected to the device.
SAS drive cables	The SAS cables connect the two RAID ports in the appliance to the two SAS IN ports in the storage shelf.	One or both SAS drive cables fail to connect the two RAID ports in the appliance to the two SAS IN ports in the storage shelf.
SAS drive cables for a second storage shelf, if used	These SAS cables connect the two SAS IN ports in the second shelf to the two SAS OUT ports in the first shelf.	One or both SAS drive cables fail to connect the second storage shelf to the first storage shelf.

Turning on the storage shelf

These steps should be followed in the given order when turning on the devices for the first time.

Caution: You must turn on the storage shelf **before** turning on the NetBackup appliance. When the storage shelf has initialized, proceed with turning on the NetBackup appliance.

To turn on the storage shelf

- 1 Connect both AC power connectors on the rear panel to two main AC power supply outlets.
- 2 Turn on both power switches.
- 3 Wait until the storage shelf system power LED and the global enclosure status LED on the front panel are green. Make sure that the disk status and activity LEDs on each disk drive are green. If they are not green, contact Symantec Technical Support.

See [“Storage shelf front panel”](#) on page 16.

- 4 Repeat this procedure for the second storage shelf, if one is in use.

See [“Turning on the Appliance ”](#) on page 35.

Turning on the Appliance

All devices must be correctly installed and all cables must be connected properly.

When turning on the NetBackup hardware, do not remove or handle any disks, optical fibers, or network cables. Otherwise, data may be lost and equipment may be damaged.

To turn on the NetBackup appliance

- 1 Connect both AC power connectors on the rear panel of the NetBackup appliance to two main AC power supply outlets.
- 2 Attach a monitor to the VGA plug, and a keyboard to one of the USB ports. If a KVM switch is available, attach both the monitor and keyboard to the switch, and plug the switch into the VGA.
- 3 Verify that the storage shelf has been turned on and is running properly.

- 4 Turn on the appliance, using the power button which is located on the front panel.
- 5 Determine if the NetBackup appliance is running properly.
 - Check the status of the power and activity indicator LEDs on the installed disk drives on the front panel.
 - Check the power supply LEDs on the rear panel.
 - Review all LEDs on the front panel to make sure the system status, power, hard drive, and all cable connections work properly.

See [“Checking information before turning on the devices”](#) on page 34.

NetBackup 5220 installation

This chapter includes the following topics:

- [Product documentation](#)
- [Product overview](#)
- [About hardware installation](#)
- [Installing hardware into racks](#)
- [About the cables](#)
- [Turning on the hardware](#)

Product documentation

This document describes hardware installation procedures for the NetBackup 5220 appliances running at least version 2.5. Zero, one, or two Symantec Storage Shelves can be used with the appliance. The document is available to customers and end users.

The table below lists hardware-related documentation for the NetBackup 5220 appliance and Symantec Storage Shelf.

Table 2-1 NetBackup 5220 and Symantec Storage Shelf hardware-related documentation

Document	Description
<i>Product Description</i>	Describes all aspects of the appliance and storage shelf. Provides safety, compliance, and environmental information.
<i>Safety and Maintenance Guide</i>	<p>Provides detailed safety information. Anyone who works on the hardware that is associated with the appliance and the storage shelf should understand all safety concerns.</p> <p>Provides guidelines for routine monitoring and physical maintenance of the hardware.</p>

You can find the documentation that includes information on the NetBackup 52xx appliances at the following URL:

<http://www.symantec.com/docs/DOC2792>

Documents that are provided at this location include:

- *NetBackup 52xx Appliance Administrator Guide*
- *NetBackup 52xx Command Reference Guide*
- *NetBackup 5200 Series Getting Started Guide*
- *NetBackup 52xx Appliance Troubleshooting Guide*
- *NetBackup 52xx Appliance Release Notes*

See “[Product overview](#)” on page 38.

Product overview

The NetBackup 5220 is an integrated high-density and high-performance backup appliance. It encapsulates network backup needs. It is a scalable appliance with an internal capacity of 4.5 TB formatted capacity.

The appliance has the ability to add another 48 TB or 72 TB of external storage with up to two Symantec Storage Shelves. The storage shelf functions as an expansion unit that contains 16 disk drive modules. Two of the disk drives are used for parity. One disk drive is a hot spare. The remaining 13 disk drives provide storage.

The NetBackup 5220 enclosure is 2U high and the Symantec Storage Shelf enclosure is 3U high. Both devices fit into standard 19” racks.

Refer to the following sections in this document for hardware details.

See [“NetBackup 5220 front and rear panels”](#) on page 40.

See [“Symantec Storage Shelf front and rear panels”](#) on page 45.

See [“Dimensions”](#) on page 39.

See [“NetBackup 5220 Appliance front and rear panels - details”](#) on page 40.

See [Table 2-2](#) on page 41.

See [“Appliance control panel”](#) on page 43.

See [“Symantec Storage Shelf front and rear panels - details”](#) on page 46.

See [“Hardware startup sequence”](#) on page 48.

Dimensions

The heaviest devices in any equipment rack should be installed in the bottom of the rack. If heavy devices are installed at the top of the rack, the rack may tip over. Injury to personnel and damage to equipment is very possible. The Symantec Storage Shelf is heavier than the appliance. Therefore, you must install the storage shelf in the bottom of the rack. Install the appliance above the storage shelves.

The following list describes the dimensions of the appliance:

- Height: 8.7 cm (3.5")
- Width: 43.0 cm (16.9")
- Depth: 70.4 cm (27.8")
- Weight: Approximately 22.7 kg (50 lbs)

The rack rails that are provided for the NetBackup 5220 Appliance are extensible to 30" (752mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 30" (752mm) the rails and the appliance cannot be properly installed. The width of the appliance is 19" (482.6mm).

The following list describes dimensions of the storage shelf:

- Height: 13.1 cm (5.25")
- Width: 44.7 cm (17.6")
- Depth: 56.1 cm (22.1")
- Weight: 32.5 kg (71.7 lbs)

The rack rails that are provided for the Symantec Storage Shelf are extensible to 36" (914mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 36" (914mm) the

rails and the appliance cannot be properly installed. The width of the storage shelf is 19" (482.6mm).

See [“Product overview”](#) on page 38.

NetBackup 5220 front and rear panels

The following figures show the NetBackup 5220 appliance front and rear views.

Figure 2-1

Appliance front panel



Figure 2-2

Appliance rear panel



See [“Product overview”](#) on page 38.

NetBackup 5220 Appliance front and rear panels - details

This section describes the front and the rear panels, ports, and indicators of the NetBackup 5220 Appliance.

Figure 2-3

Appliance front panel - details





Table 2-2 Appliance front panel details

Number	Description
1	Appliance enclosure handle (one each on left and right sides)
2	Disk drive modules (qty 8) for 2.5" 1 TB SAS hard disk drives. Disk drive slots are labeled 0 through 7, from left to right. Slot 7 is the hot spare disk. These disk drives form a RAID 6 group. Warning: Do not rearrange the disk drives. The disks must remain in their factory-installed slots for proper operation of the appliance.
3	Disk drive module handle (qty one per disk drive module)
4	Slimline drive bay (functionality not available with NetBackup 5220)
5	Flex Bay containing two non-hot-swappable SATA hard disk drives (HDDs) . These disk drives form a RAID 1 group. The two SATA drives are built in to the appliance as system disks.
6	Control panel

The following figure shows the slot assignments for the disk drive modules in the appliance. Slot 7 contains the hot spare. The disks are formatted at the factory. Do not rearrange the disks from their original locations.

Figure 2-4 Appliance disk drive module slot locations


The following photograph and list describe the rear panel of the appliance.

Figure 2-5 Appliance rear panel details





Table 2-3 Appliance rear panel details

Number	Description
1	Low Profile PCI Express (PCIe) Add-in Card Slots (qty 2)
2	Full-height PCIe Add-in Card Slots (qty 3)
3	Upper Power Supply Module
4	Upper Power Receptacle
5	Lower Power Receptacle
6	Lower Power Supply Module
7	I/O Expansion Module (not available)
8	Remote management port, also known as the IPMI port
9	NIC2 Ethernet port to customer's production network or lab
10	NIC1 Private management Ethernet port to laptop
11 and 12	USB 2.0 ports
13	DB-9 Serial B Connector (reserved)
14	Video Graphics Array (VGA) port
15	RJ-45 Serial A Connector


The five PCIe slots are numbered from top to bottom and from left to right. The following diagram identifies the five slots.

Figure 2-6 Appliance PCIe slot numbers



When FC HBA cards are installed in slots 2 or 4 they can be used as Fibre Transfer Media Server (FTMS) cards. One port on each card is configured as the initiator port. This port is shown in yellow in the following diagram. The other port on each card is configured as the target port and is shown in blue. An FC HBA card installed in slot 3 can be used as an initiator for Tape Deduplication.

Figure 2-7 FTMS ports



See [“Product overview”](#) on page 38.

Appliance control panel

This section provides a physical view and technical specifications for the control panel in the upper right-hand corner of the appliance front panel.

Figure 2-8 Appliance control panel




Table 2-4 Appliance control panel details







Number	Image	LED Function
1		<p>Hard disk activity</p> <p>Random flashing green light indicates hard disk drive activity (SAS).</p> <p>No light indicates no hard disk drive activity.</p>
2		<p>NIC 1 Activity</p> <p>Continuous green light indicates a link between the system and the network to which it is connected.</p> <p>Flashing green light indicates network activity.</p>
3		<p>NIC 2 Activity</p> <p>Continuous green light indicates a link between the system and the network to which it is connected.</p> <p>Flashing green light indicates network activity.</p>

Table 2-4 Appliance control panel details (*continued*)

Number	Image	LED Function
4		<p>System Status Solid amber indicates a critical or non-recoverable condition.</p> <p>Solid green indicates normal operation.</p> <p>Flashing green indicates degraded performance.</p> <p>Flashing amber indicates a non-critical condition.</p> <p>No light indicates POST is running or the system is off.</p>
5		<p>Power/Sleep</p> <p>Continuous green light indicates the system has power applied to it or the system is S0 state.</p> <p>Flashing green indicates the system is in sleep or ACPI S1 state.</p> <p>No light indicates the power is off or the system is in ACPI S4 or S5 state.</p>
6		<p>System identification</p> <p>Solid blue indicates system identification is active.</p> <p>No light indicates system identification is not activated.</p>

See [“Product overview”](#) on page 38.

Symantec Storage Shelf front and rear panels

The following figures show the Symantec Storage Shelf front and rear views.

Figure 2-9 Symantec Storage Shelf front panel


Figure 2-10

Symantec Storage Shelf rear panel



See [“Product overview”](#) on page 38.

Symantec Storage Shelf front and rear panels - details

The front panel of the storage shelf contains 16 SAS disk drive modules. Two disk drives are used for parity. Slot 16 contains the disk drive that is used as a hot spare. Thirteen disk drives comprise the RAID6 storage volume.


The following illustration shows the slot assignments for the disk drives.

Figure 2-11 Storage shelf disk drive slot assignments

1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16

Each I/O module in the Symantec Storage Shelf contains three network ports; a serial port, a SAS IN port, and a SAS OUT port. A power supply with fans is located below each I/O module.

Figure 2-12 Storage Shelf rear panel



Number	Component	Function
1	Serial port	Used by Symantec Technical Support.
2	Release latch	Unlocks the I/O Modules and allows removal of the module.
3	I/O Module #1	Provides redundant connectivity from a storage shelf to an appliance, or to another storage shelf.
4	SAS_IN port	Connects a storage shelf to an appliance, or to another storage shelf.
5	SAS_OUT port	Connects a storage shelf to another storage shelf when there is more than one storage shelf.
6	I/O Module #2	Provides redundant connectivity from a storage shelf to an appliance, or to another storage shelf.
7	Power supply #1	Connects a redundant AC power source to the storage shelf.
8	Fan #1	Provides air cooling to Power Supply #1 and the inside of the storage shelf. Refer to the Hardware monitoring information in the <i>NetBackup 52xx Administrator Guide</i> for details.
9	Fan #2	Provides air cooling to Power Supply #1 and the inside of the storage shelf. Refer to the Hardware monitoring information in the <i>NetBackup 52xx Administrator Guide</i> for details.
10	Power supply #2	Connects a redundant AC power source to the storage shelf.

Number	Component	Function
11	Fan #3	Provides air cooling to Power Supply #2 and the inside of the storage shelf. Refer to the Hardware monitoring information in the <i>NetBackup 52xx Administrator Guide</i> for details.
12	Fan #4	Provides air cooling to Power Supply #2 and the inside of the storage shelf. Refer to the Hardware monitoring information in the <i>NetBackup 52xx Administrator Guide</i> for details.

See [“Connecting an appliance and one or two storage shelves”](#) on page 68.

Hardware startup sequence

The NetBackup 5220 Appliance has specific startup requirements when used with one or two storage shelves.

The startup order for the NetBackup 5220 Appliance and storage shelf follows.

- Be sure that you have a matched set of an appliance and a storage shelf.
You can refer to the yellow labels on the rear panel of the storage shelf when you remove the protective film from the storage shelf.
You can find the serial numbers of the appliance and the storage shelf on the rear of the storage shelf. On the right side of the storage shelf pull the tab from the chassis.



- The HOST number refers to the appliance.
- You can find the serial number of the appliance on the front of the appliance. On the left side of the appliance pull the tab from the appliance. Compare the serial number to the matching numbers on the storage shelf.



- Turn on the storage shelf that is attached to the appliance. Allow time for the storage shelf to initialize.
- Turn on the second storage shelf if you have a second unit. Let it initialize.
- Turn on the appliance.

Note: When all systems have initialized be sure that you do not disconnect the units or turn them off without shutting down gracefully. If you do interrupt communication between the appliance and the storage shelves you must perform additional tasks.

Change the boot order through the system BIOS.

Import the foreign configuration of the storage RAID arrays.

See [“Removing the protective film from the storage shelf”](#) on page 60.

See [“Turning on the storage shelf and the appliance”](#) on page 71.

About hardware installation

Several factors must be addressed and verified before you can install the hardware components. Best practices recommend reviewing the information in these sections before you start the work.

Hardware installation flow

The basic hardware installation flow is as follows:

- Understand the NetBackup 5220 and the Symantec Storage Shelf.
- Check safety precautions.
- Check installation requirements.
 - The rack rails that are provided for the NetBackup 5220 Appliance are extensible to 30” (752mm). This distance is the maximum depth that is

allowed between rack posts. If the distance between rack posts is longer than 30" (752mm) the rails and the appliance cannot be properly installed. The width of the appliance is 19" (482.6mm). Verify that your rack has the right amount of space to contain the appliance securely.

- The rack rails that are provided for the Symantec Storage Shelf are extensible to 36" (914mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 36" (914mm) the rails and the appliance cannot be properly installed. The width of the storage shelf is 19" (482.6mm). Verify that your rack has the right amount of space to contain the storage shelf securely.
- Unpack the devices.

Note: If the Symantec Storage Shelf is ordered at the same time as a NetBackup 5220, the RAID controller card and accessories are installed before shipment. If the storage shelf is ordered at a later time, a RAID controller card and accessories must be ordered and installed into the NetBackup 5220. Contact Symantec Technical Support as needed.

- Install rack cabinet rails for the NetBackup 5220 and Symantec Storage Shelf.
- Request a Technical Support engineer to install the RAID controller card and its accessories, if needed.
- Request a Technical Support engineer to install other PCI cards, as needed.
- Remove the protective film from the exterior of the storage shelf.
- Install the NetBackup 5220 and Symantec Storage Shelf (as needed) into a rack.
- Connect the two SAS cables between the NetBackup 5220 and the first Symantec Storage Shelf, as needed.
- Connect the two SAS cables between the first Symantec Storage Shelf and the second storage shelf, as needed.
- Plug in all AC power cables and peripherals.
- Turn on power to Storage Shelf #1 and let it initialize.
- Turn on power to Storage Shelf #2 and let it initialize.
- Turn on power to the appliance.
- Ensure that the devices are operating properly.

See [“Tools and meters”](#) on page 55.

Environmental requirements

This section describes the operating and the storage environments. Parameters include temperature, humidity, altitude, and noise. Before installing any devices, check whether the external environment satisfies the conditions for proper running of the devices.

Component	Details
Operating temperature (a)	<p>Minimum range; 10°C to 35°C</p> <p>Appliance range; 5°C to 35°C</p> <p>Storage Shelf range; 10 °C to 35°C</p>
Storage temperature	-40°C to +60°C (-40 to 70) (-40 to 60)
Transportation temperature	-40°C to +70°C (-40to 70) (-40 to 60)
Maximum temperature variation per hour	10°C/h
Operating humidity	10% RH to 80% RH (10-85) (8-80)
Operating altitude	-30.5 meters to +3000 meters (0-3000)
Transportation altitude	-30.5 meters to +3000 meters (0-3000) below 35 degrees C
Noise (b)	< 72 dBA (72) (60)

Note: a: The operating temperature ranges from 5°C to 35°C when the NetBackup 5220 Appliance is located at an altitude between –60 meters and +1800 meters. The temperature falls by 0.6°C for every increase of 100 meters when the appliance is located at an altitude between 1800 meters and 3000 meters. b: The maximum noise that is generated by the NetBackup 5220 Appliance when the ambient temperature is 25°C.

See [“Power supply overview”](#) on page 53.

See [“Electrical safety”](#) on page 53.

See [“Environmental checklist”](#) on page 51.

Environmental checklist

The following table describes the environmental checklist that must be completed before appliance installation.

Table 2-5 Environmental considerations

Item	Requirement
Facility preparation	The floor meets load-bearing requirements. Wiring troughs, ladders, and holes are ready. All construction is complete.
Air conditioning	If the temperature in the room may exceed 35°C, install air conditioners which can be restarted upon recovery from a power failure. Do not let the air conditioner blow directly on the devices.
Moisture proofing	If the relative humidity is greater than 70%, a dehumidifying device must be installed. Examples of such devices include an air conditioner that provides a dehumidification function or a special-purpose dehumidifier. Water penetration, dripping, and condensation must all be prevented in the equipment room.
Heating	If the temperature in the room is lower than the stated minimum of 10°C, heating devices are required.
Dust proof	If the equipment room is located near a potential source of dust or other particulate matter, a double aluminum alloy window and an anti-theft fire door must be installed. The devices must be separated from the door and a baffle must be used to prevent dust pollution.
Lightning strike protection	The equipment room must have a lightning protection device such as lightning rod or lightning strip. The grounding of the lightning protection device and the protective grounding of the equipment room must share a grounding body.

In addition, make sure that the following special requirements are met:

- Before installation, check whether you need to submit a qualification certificate of the installation company to the property management in charge of the installation site.
- Before transportation, ensure that the dimensions of the devices meet the requirements of the transportation passages (such as elevators and passageways).

During transportation of the devices, avoid collision with doors, walls, or other structures. Do not touch the surface of components with dirty gloves.

See [“Environmental requirements”](#) on page 51.

See [“Power supply overview”](#) on page 53.

See [“Electrical safety”](#) on page 53.

Power supply overview

The NetBackup 5220 Appliance and the Symantec Storage Shelf each have two power modules, which connect to the main AC power source. Both modules, on both devices, provide redundant power in case of failure.

Two power cords (one per appliance and storage shelf) are provided. Connect each power cord to an independent AC power source.

This section describes the requirements of the NetBackup 5220 appliance power supply. Before installing the appliance, check whether the power supply satisfies the conditions for proper running of the appliance.



If multiple NetBackup 5220 Appliances are to be installed on site, check whether the power distribution in your equipment room satisfies the power requirements. You should include the maximum input power and the quantity of devices in your planning.

Table 2-6 Power values

Component	Subcomponent	Base System	Storage Shelf
Power consumption	Maximum power consumption	750 W	580 W
Power parameters	AC voltage range	100 V to 127 V	200 V to 240 V
	AC frequency range	47 Hz to 63 Hz	47 Hz to 63 Hz

The appliance has two power modules that provide redundancy. When selecting the installation site of the appliance and storage shelves, consider the following:

See [“Environmental requirements”](#) on page 51.

See [“Power supply overview”](#) on page 53.

See [“Environmental checklist”](#) on page 51.

Electrical safety

Use the following best practices to ensure that your environment has the correct electrical setup.

- Verify proper grounding for the main AC power supply.
- Overcurrent and overload protection must be available for the entire system.

- The circuits and the associated circuit breakers must provide enough power and overload protection.
- Separate the power supply from other large distribution loads or engines to prevent possible damage to the NetBackup 5220. Examples of systems that have a large power draw include air-conditioners, elevators, or factory machines.

See [“Power supply overview”](#) on page 53.

Heat dissipation guidelines

For optimal maintenance, ventilation, and heat dissipation, pay attention to the following when installing the appliance and the storage shelf into the rack cabinet.

- For proper ventilation, the rack cabinet should be at least 100 cm (4') away from surrounding walls and at least 120 cm (4') away from any other cabinet(s).
- To keep a convective air flow between the cabinet and the equipment room, ensure there are no obstructions on all sides of the cabinet.
- It is recommended to leave 1U (1U=44.45mm) space above and below each appliance.

See [“Air flow”](#) on page 54.

Air flow

The NetBackup 5220 takes in air from the front panel (along gaps in the front) and circulates air through the system. Fans discharge air from the rear of the appliance. Air flows from front to rear. The optional bezel can be installed on the front panel without any reduction in air movement.

Figure 2-13 Air flow of the NetBackup 5220



See [“Heat dissipation guidelines”](#) on page 54.

Tools and meters

Tools, supplies, and meters required for installation are described.

- Phillips screwdrivers M3-M6
- Diagonal cutting pliers
- Knife (for opening cartons)
- ESD wrist strap
- ESD gloves
- Multimeter

Table 2-7 Tools






Name	Example
Toolkit	

Table 2-7 Tools (*continued*)

Name	Example
Multimeter	
ESD wrist strap	
ESD gloves	
Tie wraps for securing wires or cables	

Recommended documents are listed below.

Table 2-8 Documents

Type	Document Name(s)	Description
Site Drawings	Network Planning, Equipment Room Layout, and Cabling/Power Diagrams.	Architectural/construction drawings with “as-built” markups

Table 2-8 Documents (*continued*)

Type	Document Name(s)	Description
Technical documents	NetBackup 5220 Appliance and Symantec Storage Shelf: <ul style="list-style-type: none"> ■ Release notes ■ Safety and Maintenance Guide 	These documents provide additional information about using the devices.

See [“ESD-preventive measures”](#) on page 57.

ESD-preventive measures

The ESD-preventive wrist strap prevents static electricity from the human body from damaging the devices. To prevent ESD from clothes, it is recommended to wear ESD-preventive clothes. If there is no usable ESD-preventive wrist strap available, wear ESD-preventive gloves.


See [“Hardware installation flow”](#) on page 49.

Wearing an ESD-preventive wrist strap

To wear an ESD wrist strap


- 1 Stretch your hand through the ESD-preventive wrist strap.
- 2 Fasten the buckle and ensure that the ESD-preventive wrist strap fully touches your skin.

An ESD-preventive wrist strap may include a plug or a metal clip. For an ESD-preventive wrist strap with an ESD jack. Insert the grounding end of the wrist strap to the ESD jack on the cabinet, as shown below.

Figure 2-14 ESD-preventive wrist strap with a plug


For an ESD-preventive wrist strap with a metal clip, attach the metal clip to the square hole on the side of the cabinet.

Figure 2-15 ESD-preventive wrist strap with a metal clip



Ensure that the buckle of the wrist strap is fastened. Tightly insert the grounding connector into the ESD socket or the metal clip is tightly clipped to the square hole on the cabinet.

See [“Wearing ESD-preventive gloves and clothes”](#) on page 58.

Wearing ESD-preventive gloves and clothes

When moving devices, wear ESD-preventive gloves (if it is not possible to wear an ESD-preventive wrist strap), as shown below.


Figure 2-16 ESD-preventive gloves



An ESD-preventive wrist strap cannot prevent static electricity that is caused by contact between devices and a person's clothes. It is recommended to wear ESD-preventive clothes.

Be sure to fasten the buttons of the ESD-preventive clothes.

Figure 2-17 ESD-preventive clothes



See [“Ensuring rack readiness”](#) on page 59.

Ensuring rack readiness

Ensure that the rack cabinet is properly installed and grounded. The clearance between any two cabinets must be at least 120 cm (approximately 4') for convenient maintenance, adequate ventilation, and effective heat dissipation. Ensure that no enclosed space is formed by the devices in the cabinet to keep proper air transfer between the cabinet and the equipment room.

The rack rails that are provided for the NetBackup 5220 Appliance are extensible to 30" (752mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 30" (752mm) the rails and the appliance cannot be properly installed. The width of the appliance is 19" (482.6mm). Verify that your rack has the right amount of space to contain the appliance securely.

The rack rails that are provided for the Symantec Storage Shelf are extensible to 36" (914mm). This distance is the maximum depth that is allowed between rack posts. If the distance between rack posts is longer than 36" (914mm) the rails and the appliance cannot be properly installed. The width of the storage shelf is 19" (482.6mm). Verify that your rack has the right amount of space to contain the storage shelf securely.

If your rack is not the correct size, contact Symantec Technical Support.

See [“Hardware installation flow”](#) on page 49.

Installing hardware into racks

When you have all of the tools and equipment that you need, you can begin to install the hardware. It is recommended to install the storage shelf, or shelves, at the bottom of the rack, due to weight.

Removing the protective film from the storage shelf


The Symantec Storage Shelf ships with a clear, protective film on the top, bottom, and sides of the chassis. The front panel and the rear panel do not include any film. You need to remove the film before you install the storage shelf into the rack. The storage shelf does not install properly if the film is not removed.

Two yellow labels sit on top of the rear of the chassis and flop over onto the rear panel. These labels contain the serial numbers of the appliance and the storage shelf.

To remove the protective film and retain the labels

Warning: Make sure that another person is available to help lift the storage shelf.

- 1 Peel the top of the yellow labels from the protective film.



- 2 Do not discard the labels.
- 3 Peel the protective film from the top rear of the storage shelf.
- 4 Replace the labels on the top of the storage shelf or save them in a secure location. You may need to refer to the labels at a later time.
- 5 Lift up one end of the storage shelf and peel the film from the bottom of the chassis.
- 6 When approximately half of the film is removed, lift the other end of the storage shelf and remove the remaining film.
- 7 Peel the film from the sides of the storage shelf.
- 8 Discard all of the film.

See [“Installing the Symantec Storage Shelf guide rails”](#) on page 61.

Installing the Symantec Storage Shelf guide rails

Each left and right mounting rail for the Symantec Storage Shelf is shipped as a unit. The front and back of each rail slide apart a few inches to allow for precise fitting into the rack cabinet. The bottom of each rail includes a sturdy metal ledge on which the Symantec Storage Shelf sits.

To install the Symantec Storage Shelf guide rails

- 1 Obtain the left and right mounting rails. The fronts of these rails mount on the front of the vertical metal posts of the rack cabinet.
- 2 Facing the rack cabinet, align the left rail over the vertical metal post on the left side of the rack. Be sure that the support ledge is on the bottom of the rail and inside the cabinet. The storage shelf sits upon the ledge.
- 3 Place the alignment pin in the top hole of the rail. Make sure that it passes through the rack and fasten the back of the pin.
- 4 Use a standard rack screw in the bottom hole of the rail, to secure the rail to the rack.
- 5 Slide the rear of the mounting rail into the rear metal post of the rack.
- 6 Repeat these steps for the mounting rail on the right side of the rack. Be sure that the support ledge is on the bottom of the rail, inside the cabinet.

See [“Installing the Symantec Storage Shelf into a rack”](#) on page 61.

Installing the Symantec Storage Shelf into a rack

Verify that the left and right mounting rails are installed successfully.



One fully-loaded or storage shelf weighs up to 33 kg.(73 lbs). More than two people are required to move and install each device. You can remove the power supplies if you want to decrease the weight during installation.

To install the Symantec Storage Shelf into a rack

- 1 Wear an ESD-preventive wrist strap and ESD-preventive gloves.
- 2 Slide the Symantec Storage Shelf along the mounting rails into the rack cabinet.
- 3 Fasten all screws with an M4 Phillips screw driver.

- 4 Ensure that the Storage Shelf sits properly and all screws are secure.
- 5 Secure the left (1) and right (2) rack handles to the rack posts with the screws that are provided.

Symantec Storage Shelf rack handles



See [“Installing the Symantec Storage Shelf guide rails”](#) on page 61.

Installing the NetBackup 5220 guide rails

Before installing the devices in the rack cabinet, determine the installation positions of the toolless guide rails according to the installation planning of the devices.

To install the NetBackup 5220 guide rails

- 1 Looking at the front of the rack cabinet, place the left guide rail on the left post of the rack cabinet.
- 2 Keep the bottom of the guide rail parallel to the bottom of the planned installation position.
- 3 Insert the guide pins on the front and rear of the guide rails into the holes on the front and the rear posts of the cabinet.
- 4 Pull out the left and the right rail extenders as far as they extend easily and safely.

See [“Installing the NetBackup 5220 Appliance into a rack”](#) on page 62.

Installing the NetBackup 5220 Appliance into a rack

Verify that the guide rails are installed successfully.



One fully-loaded device weighs up to 33 kg.(73 lbs). More than two persons are required to move and install the device.

To install the NetBackup 5220 into a rack

- 1 Wear an ESD-preventive wrist strap and ESD-preventive gloves.

Note: Locate the three heavy screws projecting from the left and the right sides of the NetBackup 5220. These three screws fit into the three slots in the rail extenders.

- 2 Using at least two people, lift the NetBackup 5220 and place it into the rail extenders. Make sure that the rail slots securely fit the screws on the sides of the device.
- 3 Gently slide the device into the rack.
- 4 If needed, install a front mounting plate to the front of each rail, using a screw to fasten it.
- 5 Repeat the previous steps to install a guide rail to the right side of the cabinet.

See [“Installing the NetBackup 5220 guide rails”](#) on page 62.

About the cables

This chapter describes how to connect cables of the NetBackup 5220, including network cables, optical fibre cables, and power cables.

See [“Cable examples”](#) on page 63.

See [“Connecting the VGA cable \(optional\)”](#) on page 65.

See [“Connecting the network cables”](#) on page 65.

See [“Connecting the optical fibres”](#) on page 66.







See [“Connecting the NetBackup 5220 power cables”](#) on page 67.

See [“Connecting the Symantec Storage Shelf power cables”](#) on page 67.

Cable examples

The following table shows the cable examples.

Table 2-9 Cables

Component	Example
PS/2 to USB adapter cable	
KVM cable	
100/1000 Mbit/s network cable	
LC multimode fibre	
SAS interconnect cable (with RAID connectors)	
AC power cable	


See [“Connecting the VGA cable \(optional\)”](#) on page 65.

Connecting the VGA cable (optional)

Connecting the Video Graphics Array (VGA) cable is optional. You can connect the cable to a computer directly or through a Keyboard Video Mouse (KVM) adaptor or switch.

To connect the VGA cable

- 1 Insert the connector of a VGA cable into the video port on the lower left side of the rear panel of the NetBackup 5220 Appliance.



- 2 Connect the other end of the cable into a KVM switch or adapter.

See [“About the cables”](#) on page 63.

Connecting the network cables

The NetBackup 5220 appliance includes two 1Gb Ethernet ports and one remote management port. These ports are accessed on the rear panel of the device. The remote management port is for use by Symantec Technical Support staff or approved field service technicians.

Figure 2-18 Appliance network ports (rear panel)



Table 2-10 Network interface ports

Port	Details
NIC1/eth0	Private network/management Ethernet port provides a channel for system management of the NetBackup 5220. The default IP address is 192.168.1.1 .
NIC2/eth1	Public network Ethernet port provides a channel for the backup of customer data.
IPMI	Intelligent Platform Management Interface port enables remote data gathering and monitoring of hardware status. This port is used by Symantec Technical Support only.

See [“About the cables”](#) on page 63.

Connecting the optical fibres

The NetBackup 5220 supports a tape out card (Fibre Channel, FC) and a 10 GE NIC, both of which are connected to other devices through optical fibres. Using the tape out card (Fibre Channel) as an example, this section describes how to connect an optical fibre. The procedure for connecting an optical fibre to the 10GE NIC is the same as that for connecting an optical fibre to the tape out card (Fibre Channel).

Caution: The laser beams of an optical interface board or inside an optical fibre can cause eye damage. When installing or maintaining optical fibres or optical transceivers, do not look into the outlet of the optical fibre or transceiver directly.

When connecting optical fibres, note the following:

- An optical transceiver is electrostatic sensitive and should be placed in an ESD-preventive and dust-proof environment for transportation, storage, and use.
- Optical fibres and optical transceivers not in use must be protected with dust caps. If the optical transceiver is contaminated, carefully clean the optical interface.
- Keep the surface of all optical connectors clean and free from scratches.
- Do not squeeze, distort, fold, or repair an optical fibre. Do not bend the optical fibre into a circle with a radius less than 5 cm. Otherwise, the optical fibre may be damaged, which reduces the system performance or causes data loss.

To connect optical fibres

- 1 Take the cap of the optical transceiver out of the interface of the tape out card (2-port 8Gb FC HBA, Fibre Channel).
- 2 Remove an optical fibre from its packaging.
- 3 Remove the caps of the optical connectors.
- 4 Plug an optical connector into the interface of the card.
- 5 Ensure that the optical connector is securely inserted into the optical transceiver.
- 6 Connect the other optical connector of the optical fibre to an FC switch or a tape library.

See [“About the cables”](#) on page 63.

Connecting the NetBackup 5220 power cables

The appliance has two power modules, one stacked upon the other and accessible on the rear panel of the device. Each module requires a separate AC power cable and main AC power outlet.

When connecting a power cable, wear an ESD-preventive wrist strap to prevent injuries.

To connect the NetBackup 5220 power cables:

- 1 Plug one end of a power cable to a power module of the NetBackup 5220.
- 2 Plug the other end of the power cable into an AC power socket.
- 3 Connect the second power cable to the second power module and to a second power socket.
- 4 Confirm that both AC power cables are connected and that any grounds are correctly placed.

See [“Connecting the VGA cable \(optional\)”](#) on page 65.

Connecting the Symantec Storage Shelf power cables

The storage shelf has two power modules, one placed next to the other and accessible on the rear panel of the device. Each module requires a separate AC power cable and main AC power outlet. The information provided in this section applies whether you are using one or two storage shelves with the appliance.

When connecting a power cable, wear an ESD-preventive wrist strap to prevent damage to components or persons.

To connects the Symantec Storage Shelf power cables


- 1 Plug one end of a power cable to a power module of a Symantec Storage Shelf.
- 2 Plug the other end of the power cable into an AC power socket.
- 3 Connect the second power cable to the second power module and to a second power socket.
- 4 Confirm that both AC power cables are connected and that any grounds are correctly placed.

See [“About the cables”](#) on page 63.

Connecting an appliance and one or two storage shelves


The following figures show the rear panel connections between the appliance and two storage shelves. NetBackup 5220 2.5 releases and higher support the addition of one or two storage shelves.

Figure 2-19 NetBackup 5220 Appliance connected to two Symantec Storage Shelves - actual



The following figure shows the appliance that is connected to two storage shelves. In this illustration the main hardware components of the appliance and of the two storage shelves are slightly hidden. The four SAS cables and ports are more easily seen.

Figure 2-20 NetBackup 5220 Appliance connected to two Symantec Storage Shelves - ports and cables




The following schematic shows the SAS OUT ports on the appliance. SAS IN and SAS OUT ports on the storage shelves are shown. Cables connect the following:

- The SAS IN ports of Storage Shelf #1 connect to the appliance.
- The SAS OUT ports of Storage Shelf #1 connect to the SAS IN ports of Storage Shelf #2.
- The SAS OUT ports of Storage Shelf #2 do not connect to any other device.

The following schematic shows the ports that are used on the appliance and the storage shelves.

Figure 2-21 NetBackup 5220 Appliance connected to two Symantec Storage Shelves - schematic



See [“Symantec Storage Shelf front and rear panels - details”](#) on page 46.

Turning on the hardware

This section describes the steps that are required to turn on the storage shelf and the appliance.

Check before turning on

This section provides information that needs to be checked after the hardware installation and cable connections are completed, but before the device is turned on.



Ensure that you prevent personnel injuries or device damage. Before checking the device installation and cable connections, confirm that all power to the NetBackup 5220 is turned off.

Verify that the device and cables are installed correctly. The following table provides the instructions that you can use to check device installation and cable connections.

Table 2-11 Installation confirmation

Component	Correct Installation	Incorrect Installation
NetBackup 5220	The NetBackup 5220 is placed securely in the rack cabinet.	The NetBackup 5220 is slanted or loose within the rack cabinet.
Symantec Storage Shelf	The shelf, or shelves, are secured in the rack cabinet.	The shelf is slanted or loose within the rack cabinet.
AC power cables	<p>The AC power cables of the appliance are connected securely between the power modules of the device and the main AC power supply.</p> <p>The AC power cables of the storage shelf are connected securely between the power modules of the device and the main AC power supply.</p>	<ul style="list-style-type: none"> Only one power cable is connected to a device. There are no power cables connected to a device.
SAS cables	<p>SAS cables connect the RAID card in the appliance to the SAS_IN ports to the first storage shelf.</p> <p>SAS cables connect the SAS_OUT ports of the first storage shelf to the SAS_IN ports of the second storage shelf.</p>	<ul style="list-style-type: none"> SAS cables are not connected to the RAID card in the appliance. SAS cables connect the RAID card of the appliance to ports other than the SAS_IN ports of the first storage shelf. The SAS_IN ports of the second storage shelf are not connected to the SAS_OUT ports of the first storage shelf.

See [“Turning on the storage shelf and the appliance”](#) on page 71.

See [“Turning off the appliance and the storage shelves”](#) on page 73.

Turning on the storage shelf and the appliance


Caution: If you are using the appliance with one or two Symantec Storage Shelves, turn on Storage Shelf #1 first. This storage shelf is connected to the appliance. When Storage Shelf #1 has initialized, turn on Storage Shelf #2. This storage shelf is connected to Storage Shelf #1.

All devices must be correctly installed and all cables must be connected properly.

When turning on the NetBackup 5220, do not remove or handle any disks, optical fibres, or network cables. Otherwise, data may be lost and equipment may be damaged.

To turn on the appliance

- 1 Connect both AC power connectors on the rear panel, right-hand side, of the appliance to two main AC power supply outlets.



The following table lists the components of the appliance power modules.

Number	Component
1	Fan
2	Module handle
3	On/Alarm indicator
4	AC power socket
5	Spring leaf

- 2 Turn on the power from the front of the NetBackup 5220 Appliance. The power button is near the control panel on the right side of the appliance.

The On/Off switch of the NetBackup 5220 is located on the control panel on the front of the device, top right-hand side.

Figure 2-22 NetBackup 5220 control panel and On/Off switch



Figure 2-23 NetBackup 5220 On/Off switch



Refer to the Control Panel on the front right-hand side of the NetBackup 5220 for more information. System status messages scroll down the screen. Use the left, right, up, and down buttons to access messages.

Check the status of each disk drive LED on the front panel of the NetBackup 5220 to determine whether the NetBackup 5220 is operating properly. Check the power supply LEDs on the rear of the appliance to verify that they are operating properly.

See [“Check before turning on”](#) on page 70.

See [“Turning off the appliance and the storage shelves”](#) on page 73.

Turning off the appliance and the storage shelves

This section describes how to turn off the NetBackup 5220. The NetBackup 5220 is designed to run 24 hours a day. If the device needs to be maintained or the power supplies are planned to be turned off or disconnected, perform the following steps to completely turn off the device.

Do not turn off the power before the disks stop running. Otherwise, disks might be damaged and data might be lost. After shutting down the system, wait at least one minute before switching on the power again.

To turn off the NetBackup 5220

- 1 If there are one or two storage shelves attached to the appliance, you must turn off the storage shelves first.
- 2 If you have two storage shelves, turn off Storage Shelf #2 first. This shelf is attached to Storage Shelf #1. Storage Shelf #2 is not attached to the appliance.
- 3 When Storage Shelf #2 is off, turn off Storage Shelf #1. This shelf is attached to the appliance.
- 4 Log in to the NetBackup Appliance Shell Menu of the NetBackup 5220 to check for running tasks or jobs. If there are running tasks, do not turn off the device until the tasks are completed.
- 5 After the system power indicator of the NetBackup 5220 shows that the device is off, turn off the power supplies of the NetBackup 5220.
- 6 Verify that no programs or tasks are running.

See [“Check before turning on”](#) on page 70.

See [“Turning on the storage shelf and the appliance”](#) on page 71.

Initial configuration

This chapter includes the following topics:

- [About appliance configuration guidelines](#)
- [About the initial configuration pages in the NetBackup Appliance Web Console](#)
- [Performing the initial configuration on a NetBackup 52xx appliance from the NetBackup Appliance Web Console](#)
- [Performing the initial configuration on a 52xx master server appliance from the NetBackup Appliance Shell Menu](#)
- [Configuring a master server to communicate with an appliance media server](#)
- [Performing the initial configuration on a 52xx media server appliance from the NetBackup Appliance Shell Menu](#)
- [About configuring the maximum transmission unit size](#)
- [Installing NetBackup client software from the packages](#)
- [Installing NetBackup client software on clients through CIFS and NFS shares](#)

About appliance configuration guidelines

Use the following configuration guidelines when you deploy new appliances:

Table 3-1 Appliance configuration guidelines

Parameter	Description
Required names and addresses	<p>Before you start the configuration, make sure that you have the following information:</p> <ul style="list-style-type: none">■ Network IP addresses, netmask, and gateway IP addresses for the appliance.■ Network names for all appliances■ DNS or host information <p>If DNS is used, make sure that the network names of all appliances and the master server are DNS resolvable (FQHN and short name). Also, make sure that both the forward and reverse lookup are functional.</p> <p>Note: If DNS is not used, make sure that you enter the proper host entries for the appliance during the initial configuration.</p> <p>Proper host entries include the master server, any media servers that are involved with deduplication operations for this server, and any clients that must communicate with this media server.</p> <ul style="list-style-type: none">■ Password for appliance access <p>The default password for appliance access is P@ssw0rd.</p> <ul style="list-style-type: none">■ Names for NetBackup storage units <p>The Storage Name fields appear only when you configure the appliance as a media server. You can change the default names or leave them.</p> <p>Note: Only the storage unit name can be customized during the media appliance role configuration.</p> <p>The default values that appear in the NetBackup Administration Console for the storage units and disk pools are as follows:</p> <ul style="list-style-type: none">■ For the AdvancedDisk:<ul style="list-style-type: none">Default storage unit name: stu_adv_<hostname>Default disk pool name: dp_adv_<hostname>■ For the NetBackup Deduplication:<ul style="list-style-type: none">Default storage unit name: stu_disk_<hostname>Default disk pool name: dp_disk_<hostname>

Table 3-1 Appliance configuration guidelines (*continued*)

Parameter	Description
Firewall port usage	<p>Make sure that the following ports are open on any firewall that exists between a master server and a media server:</p> <ul style="list-style-type: none">■ 13724 (vnetd)■ 13720 (bprd)■ 1556 (PBX)■ 7578 (Specific for the 5220 when using TCP protocol) <p>For more information about firewall ports for NetBackup and the NetBackup appliance, see the following tech note on the Symantec Support Web site.</p> <p>http://www.symantec.com/docs/TECH178855</p>
Media server role configuration	<p>Before you configure a new appliance for the Media server role, you must first update the configuration on the master server that you plan to use with it. Whether the master server is an appliance or a traditional NetBackup master server, the name of this media server must be added to the Additional Servers list on the master server.</p> <p>Adding the media server name to the master server before you configure a media server appliance provides the following benefits during the initial configuration of the media server:</p> <ul style="list-style-type: none">■ Provides the appropriate network communication to allow the media server to become part of the NetBackup domain.■ Allows the media server to create the storage server and the disk pool entries. <p>See “Configuring a master server to communicate with an appliance media server” on page 114.</p>
Disk storage option licenses	<p>Your appliance comes with an NFR license key that expires after a specific period of time. The appliance does not provide a warning message that this license key is about to expire. Thus, Symantec recommends that you change this key to a permanent key after you install and configure the appliance. See the <i>Symantec NetBackup Appliance Administrator's Guide</i> for information and instructions on how to view and change a license key.</p> <p>Note: You must replace the keys with permanent keys before they expire.</p>

Table 3-1 Appliance configuration guidelines (*continued*)

Parameter	Description
NetBackup version compatibility	<p>NetBackup appliance Release 2.6 includes NetBackup version 7.6.</p> <p>If you plan to configure this appliance as a media server, use the following guidelines for the associated master server.</p> <ul style="list-style-type: none">■ Appliance master server The appliance master server that you plan to use with this appliance media server must use appliance software version 2.6 or later. If the appliance master server currently uses appliance software version 2.5.x or earlier, it must first be upgraded to version 2.6 before you configure this appliance.■ Traditional NetBackup master server To use an appliance media server with a traditional NetBackup master server, the master server must use NetBackup version 7.6 or later. If the NetBackup master server currently uses NetBackup version 7.5.x or earlier, it must first be upgraded to version 7.6 before you configure this appliance.

See [“About NetBackup 52xx appliance roles”](#) on page 79.

See [“About appliance system configuration sequence”](#) on page 78.

About appliance system configuration sequence

If your system includes more than one appliance or a storage expansion unit, configuration must be done in a specific order.

The following describes the proper sequence for appliance configuration, based on the system components.

Table 3-2 Appliance configuration order

System	Configuration order
Single appliance system (standalone)	Configure the appliance as a master server.
Multiple appliance system (master server and media servers)	<ul style="list-style-type: none">■ Configure the first appliance as a master server.■ Configure the remaining appliances as media servers for use with an appliance master server.
Systems that include a storage expansion unit	After all appliances have been configured, add the storage expansion unit to the server on which it is physically connected.

About NetBackup 52xx appliance roles

When you configure an appliance for the first time, you must select a role for it. The role refers to the server type as follows:

Table 3-3 Appliance role and mode descriptions

Role	Description
Master	Select this role to configure the appliance as a master server.
Media	<p>Select this role to configure the appliance as a media server.</p> <p>You must also identify the master server that you plan to use with this appliance. The master server can be either a traditional NetBackup master server or a NetBackup appliance master server.</p> <p>A traditional NetBackup master server must have NetBackup version 7.6 or later installed. A NetBackup appliance master server must have appliance software version 2.6 or later installed.</p> <p>When you select the media server role, you must also define the storage names for the following disk volumes:</p> <ul style="list-style-type: none">■ Deduplication volume■ AdvancedDisk volume

See [“About the initial configuration pages in the NetBackup Appliance Web Console”](#) on page 81.

See [“About the Symantec NetBackup 52xx Appliance initial configuration checklist”](#) on page 91.

About IPv4-IPv6-based network support

NetBackup appliances are supported on a dual stack IPv4-IPv6 network and can communicate with IPv6 clients for backups and restores. You can assign an IPv6 address to an appliance, configure DNS, and configure routing to include IPv6 based systems.

Either the NetBackup Appliance Web Console or the NetBackup Appliance Shell Menu can be used to enter the IPv4 and IPv6 address information.

Review the following considerations for IPv6 addresses:

- NetBackup appliances do not support a pure IPv6 network. An IPv4 address must be configured for the appliance, otherwise the initial configuration (which

requires the command `hostname set`) is not successful. For this command to work, at least one IPv4 address is required.

For example, suppose that you want to set the `hostname` of a specific host to `v46`. To do that, first make sure that the specific host has at least one IPv4 address and then run the following command:

```
Main_Menu > Network > Hostname set v46
```

- Only global addresses can be used, not addresses with link-local or node-local scope. Global-scope and unique-local addresses are both treated as global addresses by SUSE.

Global-scope IP addresses refer to the addresses that are globally routable. Unique-local addresses are treated as global on SUSE.

- You cannot use both an IPv4 and an IPv6 address in the same command. For example, you cannot use `Configure 9ffe::9 255.255.255.0 1.1.1.1`. You should use `Configure 9ffe::46 64 9ffe::49 eth1`.
- Embedding the IPv4 address within an IPv6 address is not supported. For example, you cannot use an address like `9ffe::10.23.1.5`.
- You can add an appliance media server to the master server if the IPv6 address and the host name of the appliance media server are available. For example, to add an appliance media server to the master server, enter the IPv6 address of the appliance media server as follows:

Example:

```
Main > Network > Hosts add 9ffe::45 v45 v45
```

```
Main > Appliance > Add v45 <password>
```

You do not need to provide the IPv4 address of the appliance media server.

- A pure IPv6 client is supported in the same way as in NetBackup.
- You can enter only one IPv4 address for a network interface card (NIC) or bond. However, you can enter multiple IPv6 addresses for a NIC or bond.
- Network File System (NFS) or Common Internet File System (CIFS) protocols are supported over an IPv4 network on appliance. NFS or CIFS are not supported on IPv6 networks.
- The NetBackup client can now communicate with the media server appliance over IPv6.
- The `Main_Menu > Network > Hosts` command supports multiple IPv6 addresses to be assigned to the same host name having one network interface card (NIC). However, only one IPv4 address can be assigned to a specific host name having one NIC using this command.
- You can add an IPv6 address of a network interface without specifying a gateway address.

For more details, see the *NetBackup Appliance Command Reference Guide*.


About the initial configuration pages in the NetBackup Appliance Web Console

NetBackup appliances let you perform the initial configuration from the NetBackup Appliance Web Console with a series of pages where you enter the appropriate information.

Welcome

Figure 3-1 shows the page that first appears when you log in to an unconfigured appliance. This page provides a summary of the initial configuration tasks.

Figure 3-1 Welcome page




Note: Symantec recommends that you click on the **download a checklist** link and use it to record all of the necessary information before you begin the configuration.

Network Configuration

Figure 3-2 shows the page that is used to enter your corporate network information.

Figure 3-2 Network configuration page



Host Configuration

Figure 3-3 shows the page that is used to enter the host identification for this appliance server.

Figure 3-3 Host configuration page

Symantec NetBackup Appliance Web Console
Version 2.6

Logout

Network Configuration

Host Configuration

Password

Date and Time

Alerting and Call Home

Registration

Appliance Role Configuration

Storage Configuration

Summary of Configuration

Host Configuration

Host Name: *

For systems that use DNS, complete the Domain Name System section. For systems that do not use DNS, complete the Host Name Resolution section.

Domain Name System

For systems that use DNS

Domain Name Suffix:

DNS IP Address(es):

Search Domain(s):

mmus.sen.symantec.co

Host Name Resolution

For systems that do not use DNS

To edit the hosts file manually, click [here](#).

IP Address	Fully qualified host name	Short host name

Back


Next

Cancel

Password change

Figure 3-4 shows the page that is used to change the password for this appliance server.


Figure 3-4 Password change page



Date and Time

Figure 3-5 shows the page that is used to set the date, the time, and the time zone for this appliance server.


Figure 3-5 Date and Time page



Alerting and Call Home

Figure 3-6 shows the page that is used to configure system alerts and the Call Home feature.

Figure 3-6 Alerting and Call Home page



Registration

Figure 3-7 shows the page that is used to identify the physical location for this appliance server.

Figure 3-7 Registration page

Symantec NetBackup Appliance Web Console
Version 7.6

Logout

✓ Network Configuration

✓ Host Configuration

✓ Password

✓ Date and Time

✓ Alerting and Call Home

• Registration

Appliance Role Configuration

Storage Configuration

Summary of Configuration

Registration

✗

The appliance was unable to contact the Symantec support site to retrieve the location and the contact information that is currently on file for this appliance. Please re-enter this information in the fields below. You can follow the instructions at the bottom of the page to update the information on file for this appliance.

Provide the appliance name that we can refer to in our communications with you.
This can be a hostname or a friendly name.

Appliance Name *

Provide the details of the physical location of the appliance.
This is the location that Symantec will use to ship parts and to send service personnel.

Company Name *

Street *

City *

State or Province *

Zip or Postal Code *

Country *

Provide the contact details of the official point of contact.
Symantec will contact this person to arrange for hardware service if it is needed.

Contact Name *

Contact Number *

Contact Email *

To provide or to change the registration information for this appliance at a later time, go to <http://my.appliance.symantec.com>.
Log into your portal, select this appliance from the list that appears, and provide the necessary information or updates.

Back

Next


Cancel

Step 6 of 8

Appliance Role Configuration (Master)

Figure 3-8 shows the page that is used to select the **Master** role for this appliance server.


Figure 3-8 Appliance Role Configuration page for Master



Appliance Role Configuration (Media)

Figure 3-9 shows the page that is used to select the **Media** role for this appliance server.


Figure 3-9 Appliance Role Configuration page for Media



Storage Configuration (AdvancedDisk)

Figure 3-10 shows the page that is used to allocate storage space for the AdvancedDisk partition and to name the storage unit and the disk pool.


Figure 3-10 Storage configuration page for AdvancedDisk



Storage Configuration (Deduplication Disk/MSDP)

Figure 3-11 shows the page that is used to allocate storage space for the MSDP (Media Server Deduplication Pool) partition and to name the storage unit and the disk pool.

Figure 3-11 Storage configuration page for Deduplication Disk/MSDP



- See “About the Symantec NetBackup 52xx Appliance initial configuration checklist” on page 91.
- See “Performing the initial configuration on a NetBackup 52xx appliance from the NetBackup Appliance Web Console ” on page 92.
- See “Performing the initial configuration on a 52xx master server appliance from the NetBackup Appliance Shell Menu” on page 108.
- See “Performing the initial configuration on a 52xx media server appliance from the NetBackup Appliance Shell Menu” on page 116.

About the Symantec NetBackup 52xx Appliance initial configuration checklist

An initial configuration checklist is provided to help you plan for the initial configuration and any future reconfiguration of your appliance.

The checklist consists of a series of tables that describe the data entry fields for each initial configuration page that appears in the NetBackup Appliance Web Console.

For a new appliance, use the checklist to record the initial configuration settings before you configure the appliance. If the appliance is ever factory reset or reimaged, the appliance must be configured again. The recorded settings in the checklist can save valuable time and help get the appliance back on line quickly.

The checklist can be found in the following locations:

- *Symantec NetBackup 52xx Appliance Hardware Installation and Initial Configuration Guide*
This document is included with every new 52xx appliance. See *Appendix A* for the checklist.
- NetBackup Appliance Web Console
When you log in to the appliance for the first time through the NetBackup Appliance Web Console, a **download checklist** link appears on the **Welcome** page. Clicking the link opens the checklist file. You can also access the checklist by clicking the online Help (?) icon from any page and searching for **checklist**.
- Symantec NetBackup online documentation
You can obtain a PDF version of the checklist to download and save to a location of your choice. The PDF file also lets you enter the settings so that you can either save or print the completed checklist.
To access the latest version of this checklist, see the following link:
www.symantec.com/docs/DOC6675

See “[About the initial configuration pages in the NetBackup Appliance Web Console](#)” on page 81.

See “[Performing the initial configuration on a NetBackup 52xx appliance from the NetBackup Appliance Web Console](#)” on page 92.

See “[Performing the initial configuration on a 52xx master server appliance from the NetBackup Appliance Shell Menu](#)” on page 108.

See “[Performing the initial configuration on a 52xx media server appliance from the NetBackup Appliance Shell Menu](#)” on page 116.

Performing the initial configuration on a NetBackup 52xx appliance from the NetBackup Appliance Web Console

After you have installed, connected, and turned on all appliance system components, you are ready to configure the server.

If you plan to configure this appliance as a media server, you must complete the following tasks on the master server before you start the initial configuration. The

following link provides specific instructions about how to accomplish the necessary tasks:

See [“Configuring a master server to communicate with an appliance media server”](#) on page 114.


- Make sure that the master server and this media server have compatible software versions.
- Add the name of this media server to the master server that you plan to use with it.
- If a firewall exists between the master server and this media server, open the appropriate ports as described in the link above.
- Make sure that the date and time of this media server matches the date and time on the master server.

The following procedure describes how to configure a new or a reimaged appliance from the NetBackup Appliance Web Console.


Caution: Before or immediately after initial configuration, you must change the default maintenance password (`P@ssw0rd`) for your appliance. This password must be provided to technical support in case you need future troubleshooting assistance. You must change the maintenance password through the NetBackup Appliance Shell Menu with one of the following commands: `Main > Settings > Password maintenance` or `Main > Support > Maintenance > passwd`. For complete information, see the *Symantec NetBackup Appliance Command Reference Guide*.

To perform the initial configuration on a NetBackup 52xx appliance from the NetBackup Appliance Web Console

- 1 On the laptop that is connected to the **NIC1** appliance port, navigate to the **Local Area Connection Properties** dialog box.
On the **General** tab, select **Internet Protocol (TCP/IP)** so that it is highlighted, then click **Properties**.



On the **Alternate Configuration** tab, perform the following tasks:



- Click **User Configured**.

- For the **IP address**, enter 192.168.229.nnn, where nnn is any number from 2 through 254 except for 233.
 - For the **Subnet mask**, enter 255.255.255.0.
 - Click **OK**.
- 2 On the laptop that is connected to the appliance, open a Web browser to the following URL:
- http://192.168.229.233**
- Make sure that you affirm the security exception to proceed.
- 3 Log on to the appliance as follows:
- For **User Name**, enter **admin**.
 - For **Password**, enter **P@ssw0rd**.
- 4 On the **Welcome to Appliance Setup** page, review the summary of information that you need to perform the initial configuration.
- **Download Configuration Checklist**
To help you with the initial configuration, click this link to open a file where you can record all of the configuration settings. Symantec recommends that you print this file and fill it out for use as you perform the configuration. Then store it in a secure location for future reference.
 - **Setup Appliance**
After you have filled out the configuration checklist, click this item to start the configuration.
- 5 On the **Appliance Hardware Inventory** page, verify that the appliance has detected the correct number of connected hardware devices.
- If any connected devices are not displayed, click **Rescan**.
- When all connected devices have been detected and are displayed, click **Next** to start the initial configuration.
- If any connected devices are still not displayed, check the following items:
- Verify that all cables are connected and secured.
 - Verify that all units are turned on and have booted up completely.
 - Verify that you have checked all of the items on the hardware check list.
 - After you have verified the previous items, click **Rescan**.
When all connected devices are displayed, click **Next** to start the initial configuration.

Note: If you cannot get all devices to display after verifying all of the previous items and rescanning, contact Symantec Technical Support.

- 6 The **Network Configuration** page contains the following tables with the necessary data entry fields to configure network connectivity:

- **Network Configuration**
- **Routing Configuration**

Enter the appropriate **Network Configuration** information as follows:

Warning: NetBackup appliances do not support configuring two IP addresses that belong to the same subnet. The appliance runs on the Linux operating system and this type of networking is a current limitation. Each bond that you create must use an IP address that belongs to a different subnet.

Note: You cannot remove an IP address if the appliance host name resolves to that IP address.

Network Configuration data entry fields

- **Network Interface**

Click on the drop-down box and select the ethernet NIC port to use for a network connection.

- **IP Address**

Enter the IP address for this appliance server.

- **Subnet Mask**

Enter the network address that identifies the IP address for this appliance server.

- **Bond Mode**

Click on the drop-down box and select the bond mode to use for the NIC ports that you want to bond.

Bonding lets you combine (aggregate) multiple network interfaces into a single logical "bonded" interface. The behavior of the bonded interfaces depends upon the mode. The default bond mode is **balance-alb**.

The available bonding modes from the drop-down list are as follows:

- **balance-rr**
- **active-backup**
- **balance-xor**
- **broadcast**
- **802.3ad**
- **balance-tlb**
- **balance-alb**

Some bond modes require additional configuration on the switch or the router. You should take additional care when you select a bond mode.

For more information about bond modes, see the following documentation:

<http://www.kernel.org/doc/Documentation/networking/bonding.txt>

After you have entered the appropriate data into all fields, you must click **+** to add and immediately plumb the selected network interface. To configure bonding, you must select multiple interfaces from the **Bond Mode** drop-down box. For IPv6 addresses, enter 64 as the **Subnet Mask**.

- After you have entered the appropriate data into all fields, click **+** to save and add the network configuration settings.

Enter the appropriate **Routing Configuration** information as follows:

Routing Configuration data entry fields

- **Destination IP**

Enter the network IP address of a destination network. The address can be either IPv4 or IPv6. Only global-scope and unique-local IPv6 addresses are allowed.

See [“About IPv4-IPv6-based network support”](#) on page 79.

- **Destination Subnet Mask**

Enter the subnet value that corresponds to the **Destination IP** address.

For the initial configuration, this field contains a default value that cannot be changed. When you configure another route, you must enter the appropriate value.

- **Gateway**

Enter the address of the network point that acts as an entrance to another network. The address can be either IPv4 or IPv6. Only global-scope and unique-local IPv6 addresses are allowed.

See [“About IPv4-IPv6-based network support”](#) on page 79.

- **Network Interface**

Click on the drop-down box and select the ethernet NIC port to use for a network connection.

- After you have entered the appropriate data into all fields, click **+** to save and add the routing configuration settings.

- 7 On the **Host Configuration** page, enter the appliance host name and the related host resolution information as follows:

Host Name Enter the fully qualified domain name (FQDN) of this appliance.

For DNS systems: Enter the following **Domain Name System** information:

- **Domain Name Suffix**

Enter the suffix name of the DNS server.

- **DNS IP Address(es)**

Enter the IP address of a DNS server, then click the **+** icon to add the address. Repeat as necessary for the number of addresses that you want to add.

The address can be either IPv4 or IPv6. For IPv6 addresses, only global-scope or unique-local addresses are allowed.

See [“About IPv4-IPv6-based network support”](#) on page 79.

To remove an address, select it from the list that appears below the data entry field and click the **x** icon.

- **Search Domain(s)**

Enter a search domain name, then click the **+** icon to add the name. Repeat as necessary for the number of search domains that you want to add.

To remove a search domain, select it from the list that appears below the data entry field and click the **x** icon.

After you have entered all of the necessary information, click **Next**.

For the systems that do not use DNS:

Enter the following **Host name resolution** information:

- **To edit the hosts file manually, click here**

If you prefer, you can add the IP address, the fully qualified host name, and the short host name directly into the `/etc/hosts` file. Click **here** to open and edit the `/etc/hosts` file file.

To enter two or more short host names, add a comma with no space between each name.

Otherwise, enter this information in the data entry fields as follows:

- **IP**

Enter the IP address of the appliance.

The address can be either IPv4 or IPv6. For IPv6 addresses, only global-scope or unique-local addresses are allowed.

See ["About IPv4-IPv6-based network support"](#) on page 79.

- **Fully qualified host name**

Enter the fully qualified host name (FQHN) of the appliance.

- **Short host name**

Enter the short name of the appliance.

To enter two or more names, add a comma with no space between each name.

After you have populated all fields, click the **+** icon. The added entries now appear below the fields.

After you have entered all of the necessary information, click **Next**.

- 8 On the **Password change** page, enter a new password to replace the default password as follows:

Note: To continue with the initial configuration of the appliance, you are not required to change the default password. However, to increase the security of your environment Symantec recommends that you change the administrator password periodically. Make sure to keep a record of the current password in a secure location.

Old admin password

Enter the factory default password (**p@ssw0rd**)

New admin password	<p>Enter the new password.</p> <p>Passwords must contain at least seven characters. Passwords with only seven characters must include all of the following requirements while longer passwords must include at least three:</p> <ul style="list-style-type: none"> ■ One upper case letter ■ One lower case letter ■ One number (0 - 9) ■ One special character (!@#\$\$%^&*(){}) <p>Passwords may begin with an uppercase letter or they may end with a number. However, when these characters appear in those positions, the password is not considered to meet the minimum requirements.</p>
Confirm new password	<p>Re-enter the new password for confirmation.</p>

After you have entered all of the necessary information, click **Next**.

- On the **Date & Time** page, enter the appropriate date and time for this appliance.

You can enter the information manually or use a Network Time Protocol (NTP) server to synchronize the appliance date and time over the network.

Time zone	To assign a time zone to the appliance, click on the Time zone drop-down box and select the appropriate time zone.
Specify date & time	<p>To enter the date and the time manually, select this option and enter the following information:</p> <ul style="list-style-type: none"> ■ In the first field, enter the date by using the mm/dd/yyyy format. Or, click on the calendar icon and select the appropriate month, day, and year. ■ In the second field, enter the time by using the hh:mm:ss format. Entries must be in the 24 hour format (00:00:00 – 23:59:59).
NTP	To synchronize the appliance with a Network Time Protocol (NTP) server, select this option and enter the NTP Server IP address.

After you have entered all of the necessary information, click **Next**.

- On the **Alerting and Call Home** page, enter the information for the appliance to send alerts or to upload status reports by email to a Symantec Call Home server.

For alerts, enter the appropriate **Alerting Configuration** information as follows:

Alerting Configuration data entry fields

To configure the appliance to upload alerts, enter the following information:

- **Notification interval (in minutes)**

Enter the interval for the appliance to upload alerts to the Symantec Call Home server. Entries must be in increments of 15 minutes.

- **Enable SNMP Alert**

Click this check box and enter the following SNMP information:

- **SNMP server**

Enter either the SNMP server host name or its IP address to define this computer. The IP address can be either IPv4 or IPv6. For IPv6, only global-scope and unique-local addresses are allowed.

- **SNMP port**

Enter the port number of the SNMP server to allow communication with this appliance.

- **SNMP community**

Enter the community name where the alerts or traps are sent.

For example, you can enter the same information that you used for the **SNMP server**. You can also enter a company name or another name like, `admin_group`, `public`, or `private`. If you do not enter anything, the default value is **Public**.

- **View SNMP MIB file**

To set up the appliance SNMP Manager to receive hardware monitoring related traps, click this link to view the content of the MIB file. Then, copy the file to another location and use the content to update the SNMP Manager.

The appliance can only accept traps in the SNMPv2c format.

- **SMTP server**

Enter either the SMTP server host name or its IP address to define this computer.

- **Software administrator email address**

Enter the email address of your software administrator so that they can receive and notifications.

- **Hardware administrator email address**

Enter the email address of your hardware administrator so that they can receive and notifications.

- **Sender email address**

Enter the email address of the appliance so that recipients can identify the source of the report.

- **SMTP account**

Enter an account name for the SMTP server.

- **Password**

To increase security, enter a password for the SMTP server.

You can configure this server to send email reports to a proxy server or to the Symantec Call Home server.

The following describes the supported proxy servers:

- Squid
- Apache
- TMG

Note: NTLM authentication in the proxy configuration is also supported.

For Call Home, enter the appropriate **Call Home Configuration** information as follows:

Call Home Configuration data entry fields

To configure the appliance to send email reports to a proxy server or to the Symantec Call Home server, enter the following information:

- **Enable Call Home**
Click this check box to enable the appliance to send email reports to the Symantec Call Home server.
- **Enable proxy server**
Click this check box to use a proxy server for email notification and provide the proxy information that follows.
- **Enable proxy Tunneling**
To enable proxy tunneling, click this check box and provide the following proxy information:
 - **Proxy server**
Enter the IP address of the server.
The IP address can be either IPv4 or IPv6. For IPv6, only global-scope and unique-local addresses are allowed.
 - **Proxy port**
Enter the port number of the proxy server to allow communication with this appliance.
 - **Proxy username**
Enter the user name for the proxy server.
 - **Proxy password**
Enter the password of the proxy server.
 - **Test Call Home**
After you have entered all of the necessary information, Symantec recommends that you click **Test Call Home** to verify communication with the Symantec server. If the test fails, check that you have entered all names, IP addresses, and port numbers correctly. If the test fails again, contact Symantec Technical Support.

After you have entered all of the necessary information, click **Next**.

- 11 On the **Registration** page, enter the following information to register this appliance with Symantec over the Internet:

Note: Registration of your NetBackup appliance helps to make sure that you are alerted to product updates and other important information about your appliance.

Appliance name	Enter the network name of the server.
Company Name	Enter your company name.
Street	Enter the street name (physical location) where this server resides.
City	Enter the city where this server resides.
State/Province	Enter the state or the province where this server resides.
Zip or Postal Code	Enter the ZIP or the Postal Code where this server resides.
Country	Enter the country where this server resides.
Contact Name	Enter the name of the primary contact, such as a network or a backup administrator for your backup environment.
Contact Number	Enter the primary phone number for the contact name. This number should be the one that is most likely to reach the contact person.
Contact Email	Enter the business email address for the Contact Name that you identified earlier.

After you have entered all of the necessary information, click **Next**.

- 12 Configure the role for this appliance server as follows:

Option or data entry field Description

Appliance Role	<div> <div> Master </div> <div> When you select this role, no further action is required. Click Next to continue. </div> </div> <div> <div> Media </div> <div> If you select this role, do not continue configuration until you have performed or verified the following configuration on the master server that you want to use with this media server. The following link provides specific instructions about how to accomplish the necessary tasks: See “Configuring a master server to communicate with an appliance media server” on page 114. </div> <div> <div> Make sure that the master server and this media server have compatible software versions. </div> <div> Add the name of this media server to the master server that you plan to use with it. </div> <div> Open the following ports on the master server to allow communication to this media server: vnetd: 13724 bprd: 13720 PBX: 1556 </div> <div> Open the following ports if the master server is an appliance master server and TCP is used: 80, 5900, and 7578. Make sure that the date and time of this media server matches with that of the master server. </div> </div> </div>
----------------	--

Master server name	<div> If you selected the Media Server role, identify the name of the master server that must communicate with this media server as follows: </div> <div> <div> For master servers with only one name and IP address: Enter the host name or the IP address of the master server and click Add. </div> <div> For clustered master servers or master servers with multiple names and IP addresses: Enter each host name or IP address in the field (one at a time) and click Add. </div> </div> <div> Note: If the master server is clustered, the first entry must be the virtual host name of the cluster. </div>
--------------------	--

- 13 On the **Storage Configuration** page, create names for the storage units and the disk pools that you plan to use, and configure the size of the disk partitions.

You can configure storage partitions for AdvancedDisk, for Deduplication (MSDP), or for both.

AdvancedDisk

Enter the following information:

- **Storage Unit Name**

Enter the name that you want to use to identify this storage unit. The name can contain any letters, numbers, or special characters. The name can include up to 256 characters.

Note: The name should not start with the minus (-) character and spaces should not be used anywhere in the name.

- **Disk Pool Name**

Enter the name that you want to use to identify this disk pool. The name can contain any letters, numbers, or special characters. The name can include up to 256 characters.

Note: The name should not start with the minus (-) character and spaces should not be used anywhere in the name.

- **Size**

Set the size for this partition by entering a precise number in the **Size** field., or click and drag the box on the gray slide bar to the desired size. The size must be set in .5 or 1-GB increments.

Deduplication Disk

Enter the following information:

■ Storage Unit Name

Enter the name that you want to use to identify this storage unit. The name can contain any letters, numbers, or special characters. The name can include up to 256 characters.

Note: The name should not start with the minus (-) character and spaces should not be used anywhere in the name.

■ Disk Pool Name

Enter the name that you want to use to identify this disk pool. The name can contain any letters, numbers, or special characters. The name can include up to 256 characters.

Note: The name should not start with the minus (-) character and spaces should not be used anywhere in the name.

■ Size

Set the size for this partition by entering a precise number in the **Size** field, or click and drag the box on the gray slide bar to the desired size.

Set the size for this partition in increments of 1-GB.

After you have entered all of the necessary information, click **Next**.

- 14 On the **Configuration Progress** page, you can monitor the progress of the appliance as it applies all of the data input from the configuration pages.

The amount of time for the configuration to complete varies and depends on the complexity of your environment.

- 15 On the **Summary of Configuration** page, review the results of the configuration. Examine the results to make sure that the configuration completed successfully.

This page also identifies any errors that may have occurred. You may need to perform the initial configuration again if errors appear in the results.

- 16 After the configuration has completed successfully, wait about 10 minutes for the NetBackup services to start. You must then use the fully qualified host name to reconnect and log into the appliance.
- 17 After all appliances are configured and operational, you are ready to install client software on the computers that you want to back up.

See [“Installing NetBackup client software from the packages”](#) on page 126.
See [“Installing NetBackup client software on clients through CIFS and NFS shares”](#) on page 128.

Performing the initial configuration on a 52xx master server appliance from the NetBackup Appliance Shell Menu

After you have installed, connected, and turned on all appliance system components, you are ready to configure the server.

If you plan to configure this appliance as a media server, you must complete the following tasks on the master server before you start the initial configuration. The following link provides specific instructions about how to accomplish the necessary tasks:

See [“Configuring a master server to communicate with an appliance media server”](#) on page 114.

- Make sure that the master server and this media server have compatible software versions.
- Add the name of this media server to the master server that you plan to use with it.
- If a firewall exists between the master server and this media server, open the appropriate ports as described in the link above.
- Make sure that the date and time of this media server matches the date and time on the master server.

The following procedure describes how to configure a new 52xx master server appliance from the NetBackup Appliance Shell Menu.

Warning: NetBackup appliances do not support configuring two IP addresses that belong to the same subnet. The appliance runs on the Linux operating system and this type of networking is a current limitation. Each bond that you create must use an IP address that belongs to a different subnet.


Note: You cannot remove an IP address if the appliance host name resolves to that IP address.

Caution: Before or immediately after initial configuration, you must change the default maintenance password (`P@ssw0rd`) for your appliance. This password must be provided to technical support in case you need future troubleshooting assistance. You must change the maintenance password through the NetBackup Appliance Shell Menu with one of the following commands: `Main > Settings > Password maintenance` **OR** `Main > Support > Maintenance > passwd`. For complete information, see the *Symantec NetBackup Appliance Command Reference Guide*.

To perform the initial configuration on a 52xx master server appliance from the NetBackup Appliance Shell Menu


- 1 On the laptop that is connected to the **NIC1** appliance port, navigate to the **Local Area Connection Properties** dialog box.

On the **General** tab, select **Internet Protocol (TCP/IP)** so that it is highlighted, then click **Properties**.



On the **Alternate Configuration** tab, perform the following tasks:

Performing the initial configuration on a 52xx master server appliance from the NetBackup Appliance Shell Menu



- Click **User Configured**.
 - For the **IP address**, enter 192.168.229.nnn, where nnn is any number from 2 through 254 except for 233.
 - For the **Subnet mask**, enter **255.255.255.0**.
 - Click **OK**.
- 2 On the laptop that is connected to the appliance, open an SSH session to 192.168.229.233 and log on to your appliance.

The logon is `admin` and the default password is `P@ssw0rd`.

After you log on, the welcome message appears in the shell menu and the prompt is at the **Main_Menu** view.

- From the **Main_Menu > Network** view, enter the following command to configure the IP address of a single network that you want your appliance to connect to.

```
Configure IPAddress Netmask GatewayIPAddress [InterfaceNames]
```

Where *IPAddress* is the new IP address, *Netmask* is the netmask, and *Gateway/IPAddress* is the default gateway for the interface. The [*InterfaceNames*] option is optional.

The *IP Address* or the *Gateway IP Address* can be an IPv4 or IPv6 address. Only global-scope and unique-local IPv6 addresses are allowed.

Remember that you should not use both IPv4 and IPv6 address in the same command. For example, you cannot use `Configure 9ffe::9 255.255.255.0 1.1.1.1..` You should use `Configure 9ffe::46 64 9ffe::49 eth1`

See [“About IPv4-IPv6-based network support”](#) on page 79.

If you want to configure multiple networks you must first configure the IP address of each network that you want to add. Then you configure the Gateway address for each network you added. You must make sure that you add the default Gateway address first. Use the following two commands:

Configure the IP address of each network	Use either of the following commands depending on whether you want to configure an IPv4 or an IPv6 address for the network interface:
--	---

To configure the IPv4 address of a network interface:

```
IPv4 IPAddress Netmask [InterfaceName]
```

Where *IPAddress* is the new IP address, *Netmask* is the netmask, and [*InterfaceName*] is optional.

Repeat this command for each IP address that you want to add.

To configure the IPv6 address of a network interface:

```
IPv6 <IP Address> <Prefix> [InterfaceNames]
```

Where *IPAddress* is the IPv6 address, *Prefix* is the prefix length, and [*InterfaceName*] is optional.

```
Configure the gateway          Gateway Add GatewayIPAddress
address for each network that [TargetNetworkIPAddress] [Netmask]
you added                     [InterfaceName]
```

Where *GatewayIPAddress* is the gateway for the interface and *TargetNetworkIPAddress*, *Netmask*, and *InterfaceName* are optional. Repeat this command to add the gateway to all of the destination networks.

The *Gateway IP Address* or the *TargetNetworkIPAddress* can be an IPv4 or an IPv6 address.

Remember that you should not use both IPv4 and IPv6 address in the same command. For example, you cannot use `Gateway Add 9ffe::3 255.255.255.0 eth1`. You should use `Gateway Add 9ffe::3 6ffe:: 64 eth1`.

- From the **Main_Menu > Network** view, use the following command to set the appliance DNS domain name.

Note: If you do not use DNS, then you can proceed to Step 7.

```
DNS Domain Name
```

Where *Name* is the new domain name for the appliance.

- From the **Main_Menu > Network** view, use the following command to add the DNS name server to your appliance configuration.

```
DNS Add NameServer IPAddress
```

Where *IPAddress* is the IP address of the DNS server.

The address can be either IPv4 or IPv6. Only global-scope and unique-local IPv6 addresses are allowed.

See [“About IPv4-IPv6-based network support”](#) on page 79.

To add multiple IP addresses, use a comma to separate each address and no space.

- From the **Main_Menu > Network** view, use the following command to add a DNS search domain to your appliance configuration so the appliance can resolve the host names that are in different domains:

```
DNS Add SearchDomain SearchDomain
```

Where *SearchDomain* is the target domain to add for searching.

- 7 This step is optional. It lets you add the IP addresses of other hosts in the appliance hosts file.

From the **Main_Menu > Network** view, use the following command to add host entries to the hosts file on your appliance.

```
Hosts Add IPAddress FQHN ShortName
```

Where *IPAddress* is the IPv4 or IPv6 address, *FQHN* is the fully qualified host name, and *ShortName* is the short host name.

See [“About IPv4-IPv6-based network support”](#) on page 79.

- 8 From the **Main_Menu > Network** view, use the following command to set the host name for your appliance.

```
Hostname Set Name
```

Where *Name* is the fully qualified host name.

With this step, NetBackup is re-configured to operate with the new host name. This process may take a while to complete.

For the command `Hostname set` to work, at least one IPv4 address is required. For example, you may want to set the host name of a specific host to v46. To do that, first ensure that the specific host has at least an IPv4 address and then run the following command.

```
Main_Menu > Network > Hostname set v46
```

- 9 From the **Main_Menu > Settings** view, use the following commands to enter the SMTP server name and the email addresses for appliance failure alerts.

Enter the SMTP server name `Email SMTP Add smtp [acct] [pass]`

Where *smtp* is the host name of the target SMTP server, *acct* is the account name for authentication to the SMTP server, and *pass* is the password for authentication to the SMTP server.

Enter email addresses

```
Email Software Add eaddr
```

Where *eaddr* is the Email address where you want to receive failure alerts from the appliance.

To enter multiple addresses, separate each address with a semi-colon.

- 10 Set the role for the appliance to a master server.

From the **Main_Menu > Appliance** view, run the following command:

```
Master
```

- 11 After all appliances are configured and operational, you are ready to install client software on the computers that you want to back up.

See [“Installing NetBackup client software from the packages”](#) on page 126.

See [“Installing NetBackup client software on clients through CIFS and NFS shares”](#) on page 128.

Configuring a master server to communicate with an appliance media server

Before you configure a new appliance for the **Media** server role, you must first update the configuration on the master server that you plan to use with it. The changes allow for appropriate communication between the master server and the new media server.

The following procedure describes how to configure a master server to communicate with a new appliance media server.

To configure a master server to communicate with a new media server

- 1 Before the new appliance is configured for the media server role, verify that the software version is compatible with the master server as follows:
 - If the master server is a NetBackup appliance:
The appliance master server must use appliance software version 2.6 or later.
 - If the master server is a traditional (non-appliance) NetBackup master server:
The master server must use NetBackup version 7.6 or later and the new media server must use appliance software version 2.6 or later.
- 2 Log in to the master server as the administrator and add the name of the new media server to the master server as follows:

For an appliance master server:

From the NetBackup Appliance Web Console:

- Click **Manage > Additional Servers > Add**.
- In the **Appliance Hostname** field, enter the fully qualified host name (FQHN) of the appliance media server that you want to add.
- Click **Add**.
If the appliance has more than one host name, you must add all of the names.

From the appliance shell menu:

- From the **Main_Menu > Appliance** view, run the following command:
`Settings > NetBackup AdditionalServers
Add media-server`
Where *media-server* is the fully qualified host name (FQHN) of the appliance media server that is not yet configured.
If the appliance has more than one host name, you must add all of the names.

For a traditional NetBackup master server:

- Log on to the NetBackup Administration Console as the administrator.
- On the main console window, in the left pane, click **NetBackup Management > Host Properties > Master Servers**.
- In the right pane, click on the master server host name.
- On the **Host Properties** window, in the left pane, click **Servers**.
- In the right pane, in the **Additional Servers** section, click **Add** and enter your appliance host name. The appliance host name should appear in the top **Additional Servers** section.
If the appliance has more than one host name, you must add all of the names.
- Click **OK** and close the **Master Server Properties** window.

- 3 If a firewall exists between the master server and the media server, open the following ports on the master server to allow communication with the media server:

Note: You must be logged in as the administrator to change port settings.

- vnetd: 13724
 - bprd: 13720
 - PBX: 1556
 - If the master server is a NetBackup appliance that uses TCP, open the following ports:
80, 5900, and 7578.
- 4 Make sure that the date and time of the media server matches the date and time on the master server. You can use an NTP server or set the time manually.
- See [“Performing the initial configuration on a NetBackup 52xx appliance from the NetBackup Appliance Web Console ”](#) on page 92.
- See [“Performing the initial configuration on a 52xx media server appliance from the NetBackup Appliance Shell Menu”](#) on page 116.

Performing the initial configuration on a 52xx media server appliance from the NetBackup Appliance Shell Menu

After you have installed, connected, and turned on all appliance system components, you are ready to configure the server.

If you plan to configure this appliance as a media server, you must complete the following tasks on the master server before you start the initial configuration. The following link provides specific instructions about how to accomplish the necessary tasks:

See [“Configuring a master server to communicate with an appliance media server”](#) on page 114.

- Make sure that the master server and this media server have compatible software versions.
- Add the name of this media server to the master server that you plan to use with it.
- If a firewall exists between the master server and this media server, open the appropriate ports as described in the link above.
- Make sure that the date and time of this media server matches the date and time on the master server.

The following procedure describes how to configure a new 52xx media server appliance from the NetBackup Appliance Shell Menu.

Warning: NetBackup appliances do not support configuring two IP addresses that belong to the same subnet. The appliance runs on the Linux operating system and this type of networking is a current limitation. Each bond that you create must use an IP address that belongs to a different subnet.


Note: You cannot remove an IP address if the appliance host name resolves to that IP address.

Caution: Before or immediately after initial configuration, you must change the default maintenance password (`P@ssw0rd`) for your appliance. This password must be provided to technical support in case you need future troubleshooting assistance. You must change the maintenance password through the NetBackup Appliance Shell Menu with one of the following commands: `Main > Settings > Password maintenance` **OR** `Main > Support > Maintenance > passwd`. For complete information, see the *Symantec NetBackup Appliance Command Reference Guide*.


To perform the initial configuration on a 52xx media server appliance from the NetBackup Appliance Shell Menu

- 1 On the laptop that is connected to the **NIC1** appliance port, navigate to the **Local Area Connection Properties** dialog box.

On the **General** tab, select **Internet Protocol (TCP/IP)** so that it is highlighted, then click **Properties**.



On the **Alternate Configuration** tab, perform the following tasks:



- Click **User Configured**.

- For the **IP address**, enter 192.168.229.**nnn**, where **nnn** is any number from 2 through 254 except for 233.
 - For the **Subnet mask**, enter **255.255.255.0**.
 - Click **OK**.
- 2 On the laptop that is connected to the appliance, open an SSH session to 192.168.229.233 and log on to your appliance.

The logon is `admin` and the default password is `P@ssw0rd`.

After you log on, the welcome message appears in the shell menu and the prompt is at the **Main_Menu** view.

- 3 From the **Main_Menu > Network** view, enter the following command to configure the IP address of a single network that you want your appliance to connect to.

```
Configure IPAddress Netmask GatewayIPAddress [InterfaceNames]
```

Where *IPAddress* is the new IP address, *Netmask* is the netmask, and *GatewayIPAddress* is the default gateway for the interface. The `[InterfaceNames]` option is optional.

The *IP Address* or the *Gateway IP Address* can be an IPv4 or IPv6 address. Only global-scope and unique-local IPv6 addresses are allowed.

Remember that you should not use both IPv4 and IPv6 address in the same command. For example, you cannot use `Configure 9ffe::9 255.255.255.0 1.1.1.1..` You should use `Configure 9ffe::46 64 9ffe::49 eth1`

See [“About IPv4-IPv6-based network support”](#) on page 79.

If you want to configure multiple networks you must first configure the IP address of each network that you want to add. Then you configure the Gateway address for each network you added. You must make sure that you add the default Gateway address first. Use the following two commands:

Configure the IP address of each network

Use either of the following commands depending on whether you want to configure an IPv4 or an IPv6 address for the network interface:

To configure the IPv4 address of a network interface:

```
IPv4 IPAddress Netmask [InterfaceName]
```

Where *IPAddress* is the new IP address, *Netmask* is the netmask, and `[InterfaceName]` is optional.

Repeat this command for each IP address that you want to add.

To configure the IPv6 address of a network interface:

```
IPv6 <IP Address> <Prefix> [InterfaceNames]
```

Where *IPAddress* is the IPv6 address, *Prefix* is the prefix length, and `[InterfaceName]` is optional.


```
Configure the gateway          Gateway Add GatewayIPAddress
address for each network that [TargetNetworkIPAddress] [Netmask]
you added                     [InterfaceName]
```

Where *GatewayIPAddress* is the gateway for the interface and *TargetNetworkIPAddress*, *Netmask*, and *InterfaceName* are optional. Repeat this command to add the gateway to all of the destination networks.

The *Gateway IP Address* or the *TargetNetworkIPAddress* can be an IPv4 or an IPv6 address.

Remember that you should not use both IPv4 and IPv6 address in the same command. For example, you cannot use `Gateway Add 9ffe::3 255.255.255.0 eth1`. You should use `Gateway Add 9ffe::3 6ffe:: 64 eth1`.

- From the **Main_Menu > Network** view, use the following command to set the appliance DNS domain name.

Note: If you do not use DNS, then you can proceed to Step 7.

```
DNS Domain Name
```

Where *Name* is the new domain name for the appliance.

- From the **Main_Menu > Network** view, use the following command to add the DNS name server to your appliance configuration.

```
DNS Add NameServer IPAddress
```

Where *IPAddress* is the IP address of the DNS server.

The address can be either IPv4 or IPv6. Only global-scope and unique-local IPv6 addresses are allowed.

See [“About IPv4-IPv6-based network support”](#) on page 79.

To add multiple IP addresses, use a comma to separate each address and no space.

- From the **Main_Menu > Network** view, use the following command to add a DNS search domain to your appliance configuration so the appliance can resolve the host names that are in different domains:

```
DNS Add SearchDomain SearchDomain
```

Where *SearchDomain* is the target domain to add for searching.

- 7 This step is optional. It lets you add the IP addresses of other hosts in the appliance hosts file.

From the **Main_Menu > Network** view, use the following command to add host entries to the hosts file on your appliance.

```
Hosts Add IPAddress FQHN ShortName
```

Where *IPAddress* is the IPv4 or IPv6 address, *FQHN* is the fully qualified host name, and *ShortName* is the short host name.

See [“About IPv4-IPv6-based network support”](#) on page 79.

- 8 From the **Main_Menu > Network** view, use the following command to set the host name for your appliance.

```
Hostname Set Name
```

Where *Name* is the fully qualified host name.

With this step, NetBackup is re-configured to operate with the new host name. This process may take a while to complete.

For the command `Hostname set` to work, at least one IPv4 address is required. For example, you may want to set the host name of a specific host to v46. To do that, first ensure that the specific host has at least an IPv4 address and then run the following command.

```
Main_Menu > Network > Hostname set v46
```

- 9 From the **Main_Menu > Settings** view, use the following commands to enter the SMTP server name and the email addresses for appliance failure alerts.

Enter the SMTP server name `Email SMTP Add smtp [acct] [pass]`

Where *smtp* is the host name of the target SMTP server, *acct* is the account name for authentication to the SMTP server, and *pass* is the password for authentication to the SMTP server.

Enter email addresses

```
Email Software Add eaddr
```

Where *eaddr* is the Email address where you want to receive failure alerts from the appliance.

To enter multiple addresses, separate each address with a semi-colon.

10 Set the role for the appliance to a media server.

Note: Before you configure this appliance as a media server, you must add the name of this appliance to the master server that must work with this appliance.

From the **Main_Menu > Appliance** view, run the following command:

Media MasterServer

Where *MasterServer* is either a standalone master server, a multihomed master server, or a clustered master server. The following defines each of these scenarios:

Standalone master server	<p>This scenario shows one master server host name. This name does not need to be a fully qualified name as long as your appliance recognizes the master server on your network. The following is an example of how the command would appear.</p> <p><i>Media MasterServerName</i></p>
Multihomed master server	<p>In this scenario, the master server has more than one host name that is associated with it. You must use a comma as a delimiter between the host names. The following is an example of how the command would appear.</p> <p><i>Media MasterNet1Name,MasterNet2Name</i></p>
Clustered master server	<p>In this scenario, the master server is in a cluster. Symantec recommends that you list the cluster name first, followed by the active node, and then the passive nodes in the cluster. This list requires you to separate the node names with a comma. The following is an example of how the command would appear.</p> <p><i>Media</i> <i>MasterClusterName,ActiveNodeName,PassiveNodeName</i></p>

Multihomed clustered master server In this scenario, the master server is in a cluster and has more than one host name that is associated with it. Symantec recommends that you list the cluster name first, followed by the active node, and then the passive nodes in the cluster. This list requires you to separate the node names with a comma. The following is an example of how the command would appear.

```
Media MasterClusterName,ActiveNodeName,
PassiveNodeName,MasterNet1Name,MasterNet2Name
```

To prevent any future issues, when you perform the appliance role configuration, Symantec recommends that you provide all of the associated master server names.

- 11 When you select the media server role, the default disk storage configuration for the appliance appears. The following example shows how the default information appears for the built-in disk storage on the appliance:

```
Available Storage = xGB
Current Storage Pool Configuration:
Deduplication Storage = xGB (100%), AdvancedDisk = 0GB (0%)
```

- 12 The configuration process asks you if you want to configure your storage as AdvancedDisk.

```
Do you want part of your storage configured as AdvancedDisk?
(yes/no): y
```

Enter **y** to configure an AdvancedDisk volume.

- 13 You are then asked to enter the size of AdvancedDisk Volume.

```
Enter Size of AdvancedDisk Volume (use a % sign if you want it as a
percent of the total, or input size is GBs): 50%
```

Enter a percentage of the total storage, or enter a value that in Gigabytes (GB).

- 14 Enter **y** to confirm the size you entered. Enter **n** if you want to change the value.
- 15 You are then prompted to enter an AdvancedDisk storage unit name if the AdvancedDisk volume size is greater than zero. In addition, you are prompted to enter a Deduplication storage unit name if the Deduplication volume size is greater than zero. You are not required to change the default names.

Enter a name for the AdvancedDisk partition. For example, `stu_adv_hostname`.

Enter a name for the NetBackup Deduplication partition. For example,

`stu_disk_hostname`

Note: The default values that appear in the NetBackup Administration Console for the storage units and disk pools are as follows:

- For AdvancedDisk:
 - Default storage unit name: `stu_adv_<hostname>`
 - Default disk pool name: `dp_adv_<hostname>`
- For Deduplication:
 - Default storage unit name: `stu_disk_<hostname>`
 - Default disk pool name: `dp_disk_<hostname>`

A confirmation message appears that states the storage unit pools have been successfully created.

- 16 After all appliances are configured and operational, you are ready to install client software on the computers that you want to back up.

See [“Installing NetBackup client software from the packages”](#) on page 126.

See [“Installing NetBackup client software on clients through CIFS and NFS shares”](#) on page 128.

About configuring the maximum transmission unit size

The MTU property controls the maximum transmission unit size for an Ethernet frame. The standard maximum transmission unit size for Ethernet is 1500 bytes (without headers). In supported environments, the MTU property can be set to larger values up to 9000 bytes. Setting a larger frame size on an interface is commonly referred to as using jumbo frames. Jumbo frames help reduce fragmentation as data is sent over the network and in some cases, can also provide better throughput and reduced CPU usage. To take advantage of jumbo frames, the Ethernet cards, drivers, and switching must all support jumbo frames. Additionally, each server interface that is used to transfer data to the appliance must be configured for jumbo frames.

Symantec recommends that if you configure the MTU property of an interface to values larger than 1500 bytes, make sure that all systems that are connected to the appliance on the specific interface have the same maximum transmission unit size. Such systems include but are not limited to NetBackup clients and remote

desktops. Also verify the network hardware, OS, and driver support on all systems before you configure the MTU property.

You can configure the MTU property for an interface by using the `SetProperty` command in the appliance shell menu.

See the `SetProperty` command in the *Symantec NetBackup Appliance Command Reference Guide*.

Installing NetBackup client software from the packages

You can install client software and the NetBackup Administration Console software on the clients that you want to back up. The log on page of the NetBackup Appliance user interface provides a **Software** link that you can use to install that software. The drop-down list shows the available operating systems that are available for you to install on.

To install the agent software to a client

- 1 Log into the client that you want to back up.
- 2 In the right pane of the landing page, click **Software**. The following list shows the choices that you have to choose from:
 - All
 - Windows
 - Linux
 - Solaris
 - AIX
 - HP
 - BSD
 - Mac OS

Note: If you choose to extract Linux, UNIX, Solaris, AIX, or BSD images, Symantec recommends that you use GNU tar version 1.16 or higher to extract all .tar packages.

See, the following Technote on the Symantec Support Web site for more information.

<http://www.symantec.com/docs/TECH154080>

- 3 Choose **All** or select an operating system from the **Operating System** drop-down.
- 4 Right-click the appropriate file under **Software** to download the agent software.
The browser writes the software files to the location you specify.
Example locations are as follows:
 - On Windows platforms, download the software to `C:\temp` or to the desktop.
 - On Linux or UNIX platforms, download the software to `/tmp`.To determine the type of hardware on your Windows system, right-click **My Computer** and select **Properties**.
- 5 Unzip or untar the software package.
- 6 Install the client software
For Windows, click on the Windows executable, **setup.exe**
For UNIX systems, run the `.install` script.
- 7 After you have successfully installed the client software, you should add the appliance master server name to the client.
 - On Windows systems, you can use the Backup, Archive, and Restore interface to add the appliance master server name on the client. Perform the following:
 - After NetBackup has been loaded on the client, open the Backup, Archive, and Restore interface.
Start > All Programs > Symantec NetBackup > Backup, Archive, and Restore
 - From the Backup, Archive, and Restore interface, select **File > Specify NetBackup Machines and Policy Type...**
 - From the **Specify NetBackup Machines and Policy Type** dialog, enter the server name in the **Server to use for backups and restores** field and click **Edit Server List** and click **OK**.
 - In the dialog box that appears, enter the fully qualified host name of the appliance master server and click **OK**.
 - Close the Backup, Archive, and Restore interface.
 - Restart the NetBackup Client Services.
 - Open a Windows Command prompt.
 - Enter `services.msc` and press **Enter**.
 - On UNIX systems, add the appliance master server name to the `bp.conf` file on the client as follows:

- On the client, navigate to the following location:
`cd /usr/opensv/netbackup`
- Enter `ls` to see the contents of the directory.
- Open the `bp.conf` file in a text editor.
- Enter the fully qualified host name of the appliance master server.
- Save your changes and close the file.

See [“Installing NetBackup client software on clients through CIFS and NFS shares”](#) on page 128.

Installing NetBackup client software on clients through CIFS and NFS shares

After all appliance configuration has been completed, you can use the following procedures to install Windows and UNIX client software on the clients that are used with NetBackup appliances. These procedures explain how to obtain the software packages through a CIFS or an NFS share.

Note: If you have existing NetBackup clients that you want to use with the appliance master server, they must be version 6.0 or later. For these clients, you only need to add the appliance master server name to the client.

To install the NetBackup client software on a UNIX client through an NFS share

- 1 On the UNIX client computer where you want to install the NetBackup client software, log on as root.
- 2 Mount the following NFS share:
`<appliance_name>:/inst/client`
- 3 Browse the files within the NFS share directory. Files that are similar to the following appear:

<code>.packages</code>	<code>clientconfig</code>	<code>quickinstall.exe</code>
<code>PC_Clnt</code>	<code>docs</code>	<code>unix-client-install</code>

4 Run the `unix-client-install` script.

This action installs the NetBackup client software.

5 Add the appliance master server name to the `bp.conf` file on the client as follows:

- On the client, navigate to the following location:
`cd /usr/openv/netbackup`
- Enter `ls` to see the contents of the directory.
- Open the `bp.conf` file in a text editor.
- Enter the fully qualified host name of the appliance master server.
- Save your changes and close the file.

See [“Installing NetBackup client software from the packages”](#) on page 126.

Initial configuration checklist

This appendix includes the following topics:

- [Symantec NetBackup 52xx Appliance initial configuration checklist](#)

Symantec NetBackup 52xx Appliance initial configuration checklist

This checklist is intended to help you plan for the initial configuration of your appliance.

For a new appliance, use the following tables to record the initial configuration settings for this appliance. If this appliance is ever factory reset or reimaged, the appliance must be configured again. The recorded settings in the checklist can save valuable time and help get the appliance back on line quickly.

When using the hard copy or printed version of this checklist, make sure to place the completed checklist in a secure location.

You can also obtain a PDF version of the checklist to download and save to a location of your choice. The PDF file also lets you enter the settings so that you can either save or print the completed checklist.

To access the latest version of this checklist, see the following link:

www.symantec.com/docs/DOC6675

Table A-1 Network Configuration

Field	Setting
Network Interface	

Table A-1 Network Configuration (*continued*)

Field	Setting
IP Address	
Subnet Mask	
Bond Mode	

Table A-2 Routing Configuration

Field	Setting
Destination IP	
Destination Subnet Mask	
Gateway	
Network Interface	

Table A-3 Host Configuration

Field	Setting
Host Name	
Domain Name System (DNS)	DNS: <ul style="list-style-type: none"> ■ _____ ■ _____ ■ _____
Host Name Resolution (no DNS)	No DNS: <ul style="list-style-type: none"> ■ _____ ■ _____ ■ _____

Table A-4 Password change

Field	Setting
Old admin password	
New admin password	
Confirm new admin password	

Table A-5 Date and time configuration

Field	Setting
Time zone	
NTP Server IP	
Date and Time	

Table A-6 Alerting Configuration

Field	Setting
Notification Interval (in 15-minute intervals)	
Enable SNMP Alert	
SNMP server (required only if you check Enable SNMP Alert)	
SNMP port	
SNMP community	
SMTP server	
Software administrator email address	
Hardware administrator email address	
Sender email address	
SMTP account	
Password	

Table A-7 Call Home Configuration

Field	Setting
Enable Call Home	
Enable proxy server	
Enable proxy tunneling	
Proxy server (required only if you check Enable proxy server)	

Table A-7 Call Home Configuration (*continued*)

Field	Setting
Proxy port (required only if you check Enable proxy server)	
Proxy user name	
Proxy password	

Table A-8 Registration

Field	Setting
Appliance Name	
Company Name	
Street	
City	
State or Province	
ZIP or Postal Code	
Country	
Contact Name	
Contact Number	
Contact Email	

Table A-9 Role Configuration

Field	Setting
Master or Media	
Master server name (required only if you check Media)	

Table A-10 AdvancedDisk storage configuration

Field	Setting
Storage Unit name	
Disk Pool Name	

Table A-10 AdvancedDisk storage configuration *(continued)*

Field	Setting
Size	

Table A-11 Deduplication (MSDP) Disk Configuration

Field	Setting
Storage Unit name	
Disk Pool Name	
Size	

Adding a second storage shelf to an operational appliance

This appendix includes the following topics:

- [About adding a second Symantec Storage Shelf to an operational NetBackup 52xx appliance](#)
- [Installing and connecting a second Symantec Storage Shelf to an operational NetBackup 52xx appliance](#)
- [Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Web Console](#)
- [Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Shell Menu](#)

About adding a second Symantec Storage Shelf to an operational NetBackup 52xx appliance

If you have a NetBackup 52xx appliance that currently includes one Symantec Storage Shelf, you can expand the disk storage of the appliance by adding another Symantec Storage Shelf.

NetBackup 52xx appliances with software version 2.5 and later let you connect up to two Symantec Storage Shelf units.

Adding a second Symantec Storage Shelf to an operational appliance requires that you perform the following tasks:

- Installing the new Symantec Storage Shelf
This task involves mounting the new unit in the rack and connecting the SAS and the power cables.
See [“Installing and connecting a second Symantec Storage Shelf to an operational NetBackup 52xx appliance”](#) on page 136.
- Adding the new disk storage space to the system
This task makes the disk storage space of the new unit available for use.
See [“Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Web Console”](#) on page 138.
See [“Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Shell Menu”](#) on page 139.


Note: When you add a second Symantec Storage Shelf to an operational appliance, Symantec recommends that you schedule this task during low system activity.

Installing and connecting a second Symantec Storage Shelf to an operational NetBackup 52xx appliance

Use the following procedure to install and connect a second Symantec Storage Shelf to an operational NetBackup 52xx appliance.

To install and connect a second Symantec Storage Shelf to an operational NetBackup 52xx appliance

- 1 Install the storage shelf in the rack.
- 2 Locate the SAS cables that are shipped with the storage shelf and connect them as described in the following diagram and text descriptions:



- Plug one end of an SAS cable into the SAS_OUT port in the leftmost I/O module of the first storage shelf. The SAS_OUT port is labeled number 2 in the figure.
 Connect the other end of this SAS cable to the SAS_IN port in the leftmost I/O module on the new storage shelf. The SAS_IN port is labeled number 1 in the figure.
 - Plug one end of the other SAS cable into the SAS_OUT port in the rightmost I/O module on the first storage shelf.
 Connect the other end of this SAS cable to the SAS_IN port in the rightmost I/O module on the new storage shelf.
- 3 Connect the power cables to the second storage shelf.

- 4 Turn on power to the new storage shelf.
- 5 To add the storage space of the new storage shelf to the system, refer to the following topics:

See [“Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Web Console”](#) on page 138.

See [“Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Shell Menu”](#) on page 139.

Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Web Console

Use the following procedure to add the new storage shelf disk space to the NetBackup appliance using the NetBackup Appliance Web Console.

To add the new storage shelf disk space to the NetBackup appliance using the NetBackup NetBackup Appliance Web Console

- 1 Launch the NetBackup Appliance Web Console and verify that the new storage system appears on the **Monitor > Hardware** page. If the new storage device does not appear, check the cable connections and make sure that the power is on.
- 2 Click **Manage > Storage**.
- 3 Select the **Disk** tab.
- 4 Click the **Click here to scan for new disks** option.
- 5 In the **Do you want to scan for new disk?** dialog box, click **OK**. The scan starts.
- 6 When the scan is complete, click **OK** to refresh the **Disk** tab.

In the **Disk** column, a new ID should appear for the new storage shelf. The new entry should have the following attributes:

- **Type = Expansion.**
 - **Status = New Available**
- 7 In the **Status** column, next to **New Available**, click **Add** to activate the storage in the RAID.

- 8 In the Confirmation dialog box, click **Yes** to start a scan.

When the process completes, the following message should appear:

Storage operation completed. Succeeded.

- 9 Click **OK** to refresh the system.

After the system refreshes, the Disks tab should show the following attributes for the new storage shelf:

- **Type = Expansion**
- **Status = In Use**
- **Unallocated = n TB**

Where n is the usable volume or disk space available in the new storage shelf.

Adding the disk space of a second Symantec Storage Shelf to an operational NetBackup 52xx appliance from the NetBackup Appliance Shell Menu

The following procedure describes how to add the new storage shelf disk space to the NetBackup appliance using the NetBackup Appliance Shell Menu.

To add the new storage shelf disk space to the NetBackup appliance using the NetBackup Appliance Shell Menu

- 1 Use PuTTY to start an SSH session to access the NetBackup Appliance Shell Menu.

Note: You can also connect a laptop, keyboard and monitor, or KVM to the appliance to access the NetBackup Appliance Shell Menu.

- 2 Log in to the NetBackup Appliance Shell Menu. The **Main_Menu** prompt appears.
- 3 Go to the **Monitor** view as follows:
Enter `monitor` and press `Enter`.
- 4 Go to the **Hardware** view as follows:
Enter `hardware` and press `Enter`.

- 5 Go to the **Show** view as follows:

Enter `show` and press `Enter`.

Information about the system appears. The **Device** column should show the new storage shelf as **Expansion Unit Storage (unit 3)**. The **Status** for the unit should appear as **Not Supported**.

- 6 Perform a scan as follows:

- At the **Main_Menu** prompt, enter `manage` and press `Enter`.
- Enter `storage` and press `Enter`.
- Enter `scan` and press `Enter`.

The scan takes a couple of minutes to complete.

- 7 View the available storage space as follows:

- Navigate to the **Storage** view.
- At the prompt, enter `Show ALL` and press `Enter`.
- In the **Disk ID** table, locate and write down or copy the ID of the disk that has the following attributes:
 - **Operating system = Expansion**
 - **Source = New Available**

- 8 From the **Storage** view, enter `add` and press `Enter`. The **Add expansion unit storage** wizard is launched.

- 9 At the prompt, enter the ID of the new expansion unit that you copied earlier and press `Enter`.

Index

Symbols

- 52xx appliance
 - initial configuration checklist 130
- 52xx master server appliance
 - initial configuration from NetBackup Appliance Shell Menu 108
 - reconfigure from USB and NetBackup Appliance Shell Menu 108
- 52xx media server appliance
 - initial configuration from NetBackup Appliance Shell Menu 116

A

- about
 - appliance configuration guidelines 75
- adding a second Symantec Storage Shelf
 - to an operational NetBackup 52xx appliance 135
- adding disk space of a second storage shelf
 - from NetBackup Appliance Shell Menu 139
 - from NetBackup Appliance Web Console 138
- appliance
 - connecting the NetBackup 5230 Appliance and a storage shelf 32
 - NetBackup 5220 LEDs 43
 - NetBackup 5230 system LEDs 13
 - rear panel 31
- appliance configuration
 - about guidelines 75
- appliance media server
 - configure master server to communicate with 114
- appliance roles
 - for NetBackup 52xx 79
- appliance system
 - configuration sequence 78

C

- cable diagram
 - NetBackup 5220 Appliance and storage shelf 69
 - NetBackup 5230 Appliance and storage shelves 32

cables

- connecting a VGA cable to a NetBackup 5220 Appliance 65
 - connecting a VGA cable to a NetBackup 5230 Appliance 29
 - connecting fibre cables to a NetBackup 5220 Appliance 66
 - connecting network cables to a NetBackup 5220 Appliance 65
 - connecting network cables to a NetBackup 5230 Appliance 31
 - connecting the power cables of a NetBackup 5220 Appliance 67
 - connecting the power cables of a storage shelf 67
 - examples 63
 - fiber 30
 - network 31
 - overview 63
 - power 33
 - SFP transceivers 30
 - types 29
 - VGA 29
- clients used with appliances
 - install client software on 128
 - configuration
 - of maximum transmission unit size 125
 - configuration sequence
 - for appliance systems 78
 - configure 52xx appliance
 - from NetBackup Appliance Web Console 92
 - configure master server
 - to communicate with appliance media server 114
 - connecting cables
 - to second storage shelf 136
 - control panel, NetBackup 5220 Appliance 43

D

- dimensions
 - NetBackup 5220 Appliance 39
 - NetBackup 5230 Appliance 11
 - storage shelf 11, 39

- documentation
 - NetBackup 5220 37
 - NetBackup 5230 11

E

- environmental specifications
 - NetBackup 5220 Appliance and storage shelf 51
 - NetBackup 5230 Appliance and storage shelf 22
- ESD wrist strap 57
- ESD-preventive measures and equipment 57

F

- front panel
 - NetBackup 5220 Appliance 40
 - NetBackup 5230 Appliance 12
 - storage shelf 16, 45
- FTMS ports
 - NetBackup 5220 Appliance 43
 - NetBackup 5230 Appliance 15

G

- guidelines
 - appliance configuration 75

H

- hardware preparation
 - check packages 20
 - electrostatic discharge prevention 22
 - NetBackup 5230 process flow 19
 - rack preparation 23
 - tools 20
- hot spare
 - NetBackup 5220 Appliance 41
 - NetBackup 5230 Appliance 12
 - storage shelf 46

I

- initial configuration
 - 52xx appliance from NetBackup Appliance Web Console 92
 - pages in the NetBackup Appliance Web Console 81
- initial configuration checklist
 - 52xx appliance 130
 - about NetBackup 52xx 91
- initial configuration of 52xx master server appliance
 - from NetBackup Appliance Shell Menu 108

- initial configuration of 52xx media server appliance
 - from NetBackup Appliance Shell Menu 116
- install client software
 - on clients used with appliances 128
- installing
 - second storage shelf 136
- IPv4 and IPv6 support 79

L

- LEDs
 - NetBackup 5220 Appliance front panel 43
 - NetBackup 5230 Appliance front panel 13
 - storage shelf front panel 16
 - storage shelf rear panel 17

M

- matching the NetBackup 5220 Appliance to a storage shelf 48
- maximum transmission unit size
 - about configuration for 125

N

- NetBackup 5220
 - environmental checklist 51
 - environmental requirements 51
 - installation preparation 49
 - required tools 55
 - startup sequence 48
- NetBackup 5220 Appliance
 - air flow 54
 - connecting to the storage shelf 68
 - control panel 43
 - dimensions 39
 - front panel 40
 - installing into a rack 62
 - installing the guide rails into the rack 62
 - power supply 53
 - rear panel 40–41
- NetBackup 5230
 - startup sequence 18
- NetBackup 5230 Appliance
 - connecting to a storage shelf 32
 - dimensions 11
 - front panel 12
 - rear panel 14
- NetBackup 52xx initial configuration checklist
 - about 91
- network ports 31

P

- pages in the NetBackup Appliance Web Console for initial configuration 81
- PCIe add-in cards
 - NetBackup 5220 Appliance slots 42
 - NetBackup 5230 Appliance slots 14
- ports
 - NetBackup 5230 Appliance private network (NIC1/eth0) 31
 - NetBackup 5230 Appliance public network 31
 - storage shelf rear panel 17
- product overview
 - NetBackup 5220 38
 - NetBackup 5230 11
- protective film
 - removing 24, 60
- protective film, removing 24, 60

R

- rack rails
 - NetBackup 5220 Appliance 62
 - NetBackup 5230 Appliance 27
 - storage shelf 25
- rear panel
 - NetBackup 5220 Appliance 40
 - NetBackup 5230 Appliance 14
 - storage shelf with a NetBackup 5230 Appliance 32
- reconfiguration of 52xx master server appliance from USB and NetBackup Appliance Shell Menu 108

S

- safety
 - electrical 53
 - equipment rack 11, 39
 - heavy equipment 28, 61
 - power cables 34, 70
- SAS cables
 - connecting a NetBackup 5220 Appliance and a storage shelf 68
 - connecting a NetBackup 5230 Appliance and a storage shelf 32
- sequence
 - for appliance system configuration 78
- SFP+
 - connecting to fiber cables 30
- small form-factor pluggable (SFP+) transceivers 30

- specifications, environmental
 - NetBackup 5220 Appliance and storage shelf 51
 - NetBackup 5230 Appliance and storage shelf 22
- startup sequence
 - NetBackup 5220 48
 - NetBackup 5230 18
- storage disk drive location
 - NetBackup 5220 Appliance 41
 - NetBackup 5230 Appliance 12
- storage shelf
 - connecting to the NetBackup 5220 Appliance 68
 - connecting to the NetBackup 5230 Appliance 32
 - dimensions 11
 - disk slot assignments 46
 - front panel 16, 45
 - installing into a rack 26, 61
 - installing the guide rails into the rack 61
 - LEDs 16
 - rack rails 25
 - rear panel 17, 45–46
 - using two shelves with the NetBackup 5220 Appliance 68
- system disk drives
 - NetBackup 5220 Appliance 40
 - NetBackup 5230 Appliance 12

V

- validation
 - appliance 35
 - initial checks 34
 - storage shelf 35